

Operation Manual

41T Series – Rev 1.5 P/N 160930-10

41T Series Programmable DC Load



TM

ADAPTIVE Power Systems

Worldwide Supplier of Power Equipment

Copyright © 2018, Adaptive Power Systems, Inc. (APS) • All Rights Reserved • No reproduction without written authorization from APS.

Entire Contents Copyright © 2018 by Adaptive Power Systems, Inc. (APS) • All Rights Reserved • No reproduction without written authorization from APS.

PAGE LEFT INTENTIONALLY LEFT BLANK FOR HARDCOPY VERSIONS OF THIS DOCUMENT



Table of Contents

1	Contact Information	8
2	Warranty & Safety Information	9
2.1	Limited Warranty	9
2.2	Service and Spare Parts Limited Warranty	9
2.3	Safety Information.....	9
2.4	Safety Notices	11
3	Product Overview	13
3.1	General Description.....	13
3.2	Operating Modes	14
3.2.1	Constant Current Mode	15
3.2.2	Constant Resistance Mode	15
3.2.3	Constant Voltage Mode	15
3.2.4	Constant Power Mode	16
3.2.5	CC+CV Mode	16
3.2.6	CP+CV Mode.....	17
3.3	Static versus Dynamic Operating Modes	17
3.3.1	Programmable Parameters.....	18
3.3.2	Slew Rates	18
3.3.3	Determining Actual Transition Times	19
3.4	Current Read-back.....	20
3.5	Analog Input Mode	20
3.6	Product Features	21
3.7	Accessories Included	22
3.7.1	Accessory Installation	23
3.8	Interface Options.....	23
4	Technical Specifications	24
4.1	Operating Ranges	24
4.2	Operating Modes	24
4.3	Protection Modes.....	25
4.4	Dynamic Operation Mode	26
4.5	Metering	26
4.6	Miscellaneous	27
4.7	AC Input & Cooling	28
4.8	Dimensions & Weight	28
4.8.1	Modules Loads.....	28
4.8.2	Bench Models	28
4.9	Environmental	28
4.10	Voltage versus Current Operating Envelope Charts.....	29
4.10.1	Model 41T0630 V-I Curves.....	30
4.10.2	Model 41T0660 V-I Curves.....	31
4.10.3	Model 41T2512 V-I Curves.....	32
4.10.4	Model 41T5012 V-I Curves.....	33
4.10.5	Model 41T0615 V-I Curves.....	34
4.10.6	Model 41T0880 V-I Curves.....	35
4.10.7	Model 41T5020 V-I Curves.....	36
4.10.8	Model 41T08160 / 41T08160M V-I Curves	37
4.10.9	Model 41T5040 / 41T5040M V-I Curves	38
5	Unpacking and Installation	39
5.1	Inspection	39

5.2	Load Module Installation and Removal in Mainframe.....	39
5.2.1	Module Removal	39
5.2.2	Module Installation	40
5.3	Cleaning.....	41
5.4	Powering Up	41
5.5	In Case of Malfunction	41
5.6	Load Connections.....	42
5.7	Analog Programming Input.....	43
5.8	Load Current Slew Rate.....	44
6	Front Panel Operation	46
6.1	Front Panel Layout	46
6.2	User Controls and Readouts	47
6.3	For more information on using the MPPT operation mode, refer to section 6.7, "TURBO Mode..."	60
6.4	Power Supply Overload Testing.....	60
6.4.1	SHORT Test Mode in Normal and Turbo Mode	62
6.4.2	Over Current Protection Mode in Normal and Turbo Mode	62
6.4.3	Over Power Protection Mode in Normal and Turbo Mode	63
6.5	Operating Flowchart for 41T Series Load Modules	70
6.6	Go/NoGo LIMIT Testing	71
6.6.1	Limits	71
6.6.2	Go/NoGo Testing in CC Mode.....	71
6.6.3	Go/NoGo Testing in CC Dynamic Mode	72
6.6.4	Go/NoGo Testing in CR Mode.....	72
6.6.5	Go/NoGo Testing in CV Mode	73
6.6.6	Go/NoGo Testing in CP Mode.....	73
6.7	TURBO Mode	74
6.8	Power Supply Overload Testing.....	75
6.8.1	SHORT Test Mode in Normal and Turbo Mode	76
6.8.2	Over Current Protection Mode in Normal and Turbo Mode	77
6.8.3	Over Power Protection Mode in Normal and Turbo Mode	77
6.9	MPPT Mode	78
6.9.1	PV Panel Maximum Power Point.....	78
6.9.2	DC Load vs Inverter MPPT Algorithms.....	78
6.9.3	Load MPPT Algorithm.....	78
6.9.4	Manual MPPT Mode Operation	80
6.9.5	Remote MMPT Programming.....	80
6.10	Protective Current Device Test Mode	81
6.11	BMS Test Mode	83
6.12	Battery Test Modes	84
6.13	NTC Simulation (Option)	85
6.14	Initial Power-on Settings	86
6.14.1	Model 41T0630 Initial Settings	86
6.14.2	Model 41T0660 Initial Settings	87
6.14.3	Model 41T2512 Initial Settings	88
6.14.4	Model 41T5012 Initial Settings	89
6.14.5	Model 41T0615 Initial Settings	90
6.14.6	Model 41T0880 Initial Settings	91
6.14.7	Model 41T5020 Initial Settings	92
6.14.8	Model 41T0160 / 41T08160M Initial Settings	93
6.14.9	Model 41T5040 / 41T5040M Initial Settings.....	94
7	Load Connections, Applications and Protection Features	95
7.1	INPUT Terminals	95

7.1.1	Banana Jack Connectors.....	95
7.1.2	Y-hook / Spade Lug Terminals.....	95
7.1.3	Lead Wire Insertion	95
7.1.4	Banana Jack Connector and Spade Lug Terminals.....	95
7.1.5	Plug Connector and Lead Wire Insertion	96
7.2	Wire Size	96
7.2.1	Wire Size Guidelines	96
7.3	Connecting a UUT.....	97
7.4	Polarity and Ground – Multiple Output Power Supplies.....	98
7.5	Voltage Sense Input Terminals	99
7.6	Current Output Monitor (I-Monitor).....	100
7.6.1	Non-Isolated Output	100
7.6.2	Output Impedance	101
7.6.3	Connecting I-Monitor Output to an Oscilloscope.....	102
7.7	Parallel Operation.....	103
7.7.1	Parallel Mode Connection.....	103
7.7.2	Allowable Operating Modes	103
7.7.3	Exceptions	103
7.8	Series Operation	103
7.9	Zero-Voltage Loading	104
7.10	Protection Features.....	105
7.10.1	Over Voltage Protection.....	105
7.10.2	Over Current Protection.....	105
7.10.3	Over Power Protection.....	105
7.10.4	Over Temperature Protection	106
7.10.5	Reverse Polarity Protection Indication	106
8	Auto Sequence Programming Examples	107
8.1	Overview	107
8.2	Edit Mode	107
8.3	Test Mode	108
8.4	AUTO TEST SEQUENCE Example	109
9	Short Circuit, OPP and OCP Test Examples	111
9.1	Overview	111
9.2	SHORT Test	111
9.3	OPP Test.....	112
9.4	OCP Test.....	113
10	Remote Control Programming.....	114
10.1	Overview	114
11	Calibration	115
11.1	Overview	115
11.2	Calibration Interval.....	115
11.3	Calibration Coefficients	115
11.4	Calibration Procedures.....	115
12	CE MARK Declaration of Conformity.....	116
13	RoHS & REACH Material Content Declaration	117
	Index	118

Table of Tables

Table 3-1: Dynamic Current Mode Parameters.....	18
Table 3-2: Included Accessories	22
Table 6-1: Front Panel Display and Keyboard Functions	69
Table 6-2: Short / OCP / OPP Capabilities.....	75
Table 6-3: MMP Tracking Perturbation and Observation Table.....	80
Table 6-4: FUSE Test Mode Capabilities	81
Table 6-5: Model 41T0630 Power-on Settings	86
Table 6-6: Model 41T0660 Power-on Settings	87
Table 6-7: Model 41T2512 Power-on Settings	88
Table 6-8: Model 41T5012 Power-on Settings	89
Table 6-9: Model 41T0615 Power-on Settings	90
Table 6-10: Model 41T0880 Power-on Settings	91
Table 6-11: Model 41T5020 Power-on Settings	92
Table 6-12: Model 41T08160 / 41T08160M Power-on Settings	93
Table 6-13: Model 41T5040 / 41T5040M Power-on Settings	94
Table 7-1: Load Wire Size Table.....	96
Table 7-2: Multiple Output DC Supply Polarity Connection	98
Table 8-1: Auto-Test Sequence Example Values	109

Table of Figures

Figure 3-1: Dynamic Current Wave Form	17
Figure 3-2: Rise Time Performance Limits	19
Figure 3-3: 41T Series Accessories.....	22
Figure 5-1: Load Module Removal.....	40
Figure 5-2: Location and Pin-out of Analog Programming Input Connector	43
Figure 5-3: Channel Positions for Analog Input Identification.....	43
Figure 5-4: Analog Programming Example	44
Figure 5-5: Effect of Current Slew Rate Settings on Power Supply Testing	45
Figure 6-1: 41T08160 Load Front Panel View	46
Figure 6-2: Front Panel User Controls and Indicators	47
Figure 6-3: Operation Flow Chart - 41T Series Load Module	70
Figure 6-4: LIMIT Test in CC Mode.....	71
Figure 6-5: LIMIT Test in Dynamic CC Mode.....	72
Figure 6-6: LIMIT Test in CR Mode	72
Figure 6-7: LIMIT Test in CV Mode	73
Figure 6-8: LIMIT Test in CP Mode.....	73
Figure 6-9: MMP Tracking Perturbation and Observation Chart.....	79
Figure 7-1: Doubling wire size using spade lugs	96
Figure 7-2: DC Load Connection with Internal Voltage Sense	99
Figure 7-3: DC Load Connection with External Voltage Sense	99
Figure 7-4: Equivalent I-Monitor Output Circuit	101
Figure 7-5: Correct I-Monitor Connections to UUT and Oscilloscope	102
Figure 7-6: Incorrect I-Monitor Connections to UUT and Oscilloscope.....	102

Figure 7-7: Parallel Load Connection.....	103
Figure 7-8: Zero Volt Load Connection.....	104
Figure 8-1: Auto-Test Sequence Example Illustration	109

1 Contact Information

AMERICA / CANADA

Adaptive Power Systems
Irvine, USA
Phone: +1(949) 752-8400
Fax: +1 (949) 756-0838
Email: support@adaptivepower.com

EUROPE

Caltest Instruments GmbH.
Kappelrodeck
Phone: +49(0)7842-99722-00
Fax: +49(0)7842-99722-29
Email: support@adaptivepower.com

ASIA

PPST Shanghai Co. Ltd.
Shanghai, China
Phone: +86-21-6763-9223
Fax: +86-21-5763-8240
Email: support@adaptivepower.com

Web: <https://www.adaptivepower.com>

2 Warranty & Safety Information

2.1 Limited Warranty

Adaptive Power Systems, Inc. (APS) warrants each unit to be free from defects in material and workmanship. For the period of one (1) year from the date of shipment to the purchaser, APS will either repair or replace, at its sole discretion, any unit returned to the APS factory in Irvine, California or one of its designated service facilities. It does not cover damage arising from misuse of the unit or attempted field modifications or repairs. This warranty specifically excludes damage to other equipment connected to this unit.

Upon notice from the purchaser within (30) days of shipment of units found to be defective in material or workmanship, APS will pay all shipping charges for the repair or replacement. If notice is received more than thirty (30) days from shipment, all shipping charges shall be paid by the purchaser. Units returned on debit memos will not be accepted and will be returned without repair.

This warranty is exclusive of all other warranties, expressed or implied.

2.2 Service and Spare Parts Limited Warranty

APS warrants repair work to be free from defects in material and workmanship for the period of ninety (90) days from the invoice date. This Service and Spare Parts Limited Warranty applies to replacement parts or to subassemblies only. All shipping and packaging charges are the sole responsibility of the buyer. APS will not accept debit memos for returned power sources or for subassemblies. Debit memos will cause return of power sources or assemblies without repair.

This warranty is exclusive of all other warranties, expressed or implied.

2.3 Safety Information

This chapter contains important information you should read BEFORE attempting to install and power-up APS Equipment. The information in this chapter is provided for use by experienced operators. Experienced operators understand the necessity of becoming familiar with, and then observing, life-critical safety and installation issues. Topics in this chapter include:

- Safety Notices
- Warnings
- Cautions
- Preparation for Installation
- Installation Instructions



Make sure to familiarize yourself with the **SAFETY SYMBOLS** shown on the next page. These symbols are used throughout this manual and relate to important safety information and issues affecting the end user or operator.

SAFETY SYMBOLS



Direct current (DC)



Alternating current (AC)



Both direct and alternating current



Three-phase alternating current




Protective Earth (ground) terminal



On (Supply)



Off (Supply)



Fuse



Caution: Refer to this manual before this Product.



Caution, risk of electric shock

2.4 Safety Notices

SAFETY SUMMARY

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Adaptive Power Systems assumes no liability for the customer's failure to comply with these requirements.

GENERAL

This product is a Safety Class 1 instrument (provided with a protective earth terminal). The protective features of this product may be impaired if it is used in a manner not specified in the operation instructions.

ENVIRONMENTAL CONDITIONS

This instrument is intended for indoor use in an installation category I, pollution degree 2 environments. It is designed to operate at a maximum relative humidity of 80% and at altitudes of up to 2000 meters. Refer to the specifications tables for the ac mains voltage requirements and ambient operating temperature range.

BEFORE APPLYING POWER

Verify that the product is set to match the available line voltage and the correct fuse is installed.

GROUND THE INSTRUMENT

This product is a Safety Class 1 instrument (provided with a protective earth terminal). To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument must be connected to the AC power supply mains through a properly rated three-conductor power cable, with the third wire firmly connected to an electrical ground (safety ground) at the power outlet. Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury.

FUSES

Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used. Do not use repaired Fuses or short circuit the fuse holder. To do so could cause a shock or fire hazard.

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE.

Do not operate the instrument in the presence of flammable gases or fumes.

KEEP AWAY FROM LIVE CIRCUITS.

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified service personnel. Do not replace components with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power, discharge circuits and remove external voltage sources before touching components.

DO NOT SERVICE OR ADJUST ALONE.

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT EXCEED INPUT RATINGS.

This instrument may be equipped with a line filter to reduce electromagnetic interference and must be connected to a properly grounded receptacle to minimize electric shock hazard. Operation at line voltages or frequencies in excess of those stated on the data plate may cause leakage currents in excess of 5.0 mA peak.

DO NOT EXCEED LOAD INPUT VOLTAGE RATING.**WARNING****DO NOT EXCEED LOAD INPUT VOLTAGE RATING**

This instrument does NOT have a means to disconnect its Load input from a connected power supply. If the voltage applied to the Load input exceeds its maximum rating – even if the load is turned completely off – damage to the load WILL occur. Damage caused by exceeded maximum load input voltage under any circumstance is NOT covered by the manufacturer's product warranty. Remove any load input connections when the load is not in use, even when it is turned off.

DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT.

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to an Adaptive Power Systems Sales and Service Office for service and repair to ensure that safety features are maintained.

Instruments that appear damaged or defective should be made inoperative and secured against unintended operation until they can be repaired by qualified service personnel.

3 Product Overview

This chapter provides an overview of the APS 41T Series modular programmable DC loads. It introduces the reader to general operating characteristics of these loads.

3.1 General Description

The APS 41T Series modular electronic loads are designed to perform test, evaluation and burn-in of DC power supplies and batteries.

The 41T Series of electronic load modules are operated from within a suitable mainframe. The 44M01T, 44M02T and 44M04T mainframes allow 1, 2 or 4 modules to be operated at the same time. The mainframes provide the necessary mains power conversion along with computer and analogue interfaces. Front panel memory store and recall functions are provided. A total of 150 memory locations are available to store the set-up of the load modules within a mainframe. It is also possible to program and recall a test sequence consisting of different steps against time. Please refer to the separate 44M01T, 44M02T and 44M04T operating manuals for the mainframe functions.

Mainframe model 44M01T: P/N 160901-10

Mainframe model 44M02T: P/N 160902-10

Mainframe model 44M04T: P/N 160904-10

The APS 41T Series can be operated from the front panel (manual mode) or using RS232, USB, LAN (Ethernet) or GPIB remote control.

The VI curve constant power contours of the various 41T Series modules are shown in the Technical Specification Section. All models have dual range capability for enhanced accuracy and resolution at lower power levels. Maximum current and power capability depends on the specific module type.

The 41t08160 and 41T5040 are available in either double-wide modular form factor or as standalone bench unit. Modular versions of these loads have an M suffix. Modular version is shown below on the left using a 44M04T mainframe, stand-alone version shown on the right.



3.2 Operating Modes

Available operating modes for all models are:


- Constant Current (CC) mode
- Constant Resistance (CR) mode
- Constant Voltage (CV) mode
- Constant Power (CP) mode.

A more detailed explanation of each mode and under what condition each mode is most appropriate to use follows.

3.2.1 Constant Current Mode

This is the most commonly used mode of operating when testing a voltage source such as a DC power supply, battery, AC/DC converter or ADC. In this mode of operation, the load will sink a constant level of current as set by the user, regardless of any voltage variations. A real time feedback loop ensures a stable current under any voltage variation of the DC supply or battery.

This mode is recommended for load regulation testing, loop stability testing, battery discharge testing and any other form of voltage regulation loop testing.




3.2.2 Constant Resistance Mode

In Constant Resistance mode, the load will sink current directly proportional to the sensed DC input voltage. The ratio between DC voltage and current is linear per ohms law and can be set by the user within the operating range of the DC load. The current is defined by the formula shown here where R is the set value in CR mode and V is the dc input voltage from the unit under test.

$$I = V/R$$


CR mode is useful for battery discharge testing of battery systems used to power constant impedance loads as the voltage will decrease as the battery discharges over time resulting in reduced current sinking.



3.2.3 Constant Voltage Mode

In Constant Voltage mode, the load will attempt to sink as much current as needed to reach the programmed voltage setting. This mode should only be used with current controlled DC power sources.

Note: Most DC power supplies are voltage controlled, i.e. they regulate the output voltage to a predefined voltage level. Such DC voltage supplies should not be tested using CV mode as the DC supply voltage regulation loop will conflict with the DC load control loop.




3.2.4 Constant Power Mode

In Constant Power mode, the DC load will attempt to maintain the programmed Power dissipation by sinking more or less current at the voltage sensed. The current is defined by the formula shown below.

$$I = P/V$$


Constant power mode is useful for battery discharge testing as it simulates constant power drain on the battery, regardless of battery charge state.



3.2.5 CC+CV Mode

When the DC load is used in constant current mode, it is possible to add CV mode as well by selecting the add.CV setting. This will place the load in CC+CV mode. In this mode, the DC load operates like a shunt regulator as shown in the figure below. Operating as a constant current load, the load sinks the specified CC current setting level regardless of the DC input voltage from the Battery. When the battery voltage (VM) rises above the CV set point level, the DC load reverts to CV mode of operation, keeping the voltage constant by adjusting the dc current as needed. If VM is less than or equal to the CV set point V, no current will flow.


The load will transition between both modes automatically. In the illustration below, R1 is the internal impedance of the battery or other type of constant voltage power supply. Note that while in CV mode, the DC load may be unstable if R1 is very low.



3.2.6 CP+CV Mode

The CC+CP mode is a combination of constant current and the constant power modes and is also intended for battery test applications. When the load is used in constant current mode, it is possible to add CP mode as well by selecting the add.CP setting.

This mode operates in a similar fashion as the CC+CV mode but operates in a constant power mode until the power exceeds the power setting at which point the load transitions to constant voltage mode of operation.



3.3 Static versus Dynamic Operating Modes

The 41T Series supports both STATIC and DYNAMIC CC mode. Static mode uses a constant load level whereas dynamic mode allows rapid changes between two pre-set current sink levels using programmable current slew rates and duty cycle.

Static Constant Current mode presents a static load condition as the load current remains constant. This tests load regulation of a DC power supply under steady state operating conditions.

To test voltage regulation under dynamic load conditions, specific changes in current level and current slew rates must be applied to the DC supply under test. The dynamic CC mode is provided for this application.

The 41T Series offer a wide range of dynamic load conditions with independent rise and fall current slew rate programming in Constant Current mode.




Figure 3-1: Dynamic Current Wave Form

3.3.1 Programmable Parameters

There are six programmable parameters to generate dynamic wave form or pulse wave form, the 41T Series loads will sink current from power source proportional to the dynamic wave form, the dynamic wave form definition is shown in Figure 3-1. Available settings are:

Parameter	Description	Type
Current High	Highest programmed load current	Current Setting
Current Low	Lowest programmed load current	Current Setting
T-High	Duration at High current setting	Time (secs)
T-Low	Duration at Low current setting	Time (secs)
Rising Slew Rate	Current Slew Rate from Low to High Current	A/sec
Falling Slew Rate	Current Slew Rate from High to Low Current	A/sec

Table 3-1: Dynamic Current Mode Parameters

The resulting Current Waveform has the following characteristics:

$$\text{Period} = T\text{-High} + T\text{-Low}$$

$$\text{Frequency} = 1 / (T\text{-High} + T\text{-Low})$$

$$\text{Duty Cycle} = T\text{-High} / (T\text{-High} + T\text{-Low})$$

3.3.2 Slew Rates

Slew rate is defined as the change in current or voltage over time. A programmable slew rate allows a controlled transition from one load setting to another to minimize induced voltage drops on inductive power wiring, or to control induced transients on a test device (such as would occur during power supply transient response testing).

In cases where the transition from one setting to another is large, the actual transition time can be calculated by dividing the voltage or current transition by the slew rate. The actual transition time is defined as the time required for the input to change from 10% to 90% or from 90% to 10% of the programmed current excursion. In cases where the transition from one setting to another is small, the small signal bandwidth of the load limits the minimum transition time for all programmable slew rates. Because of this limitation, the actual transition time is typically longer than the expected time based on the slew rate setting, as shown in Figure 3-2.

Therefore, both minimum transition time and slew rate must be considered when determining the actual transition time. *See also section 5.8 "Load Current Slew Rate" on page 44.*




Figure 3-2: Rise Time Performance Limits

3.3.3 Determining Actual Transition Times

The minimum transition time (Tr_{min}) for a given slew rate applies for smaller changes in current as a percent of current range. At about a 30% or greater load change, the slew rate starts to increase from the minimum transition time to the maximum transition time (Tr_{max}) at a 100% load change. The actual transition time will be either the minimum transition time, or the total slew time (T-fall or T-rise) divided by the current slew rate, whichever is longer.

Minimum Tr

Use the following formulas to calculate the minimum transition time for a given slew rate on a 41T0660 module:

Maximum current range for this module is 60A so 30% of 60 = 18. The minimum required slew rate can be calculated as follows:

$$Tr_{min} = \frac{18}{\text{slew rate (A/}\mu\text{s)}} * \frac{(90\% - 10\%)}{100\%} \mu\text{s}$$

Which is equivalent to:

$$Tr_{min} = \frac{18}{\text{slew rate (A/}\mu\text{s)}} * 0.8 \mu\text{s}$$

For a programmed slew rate of 0.1A/ μ s, this results in:

$$Tr_{min} = \frac{18}{0.1} * 0.8 \mu\text{s} = 144 \mu\text{s}$$

Example 1:

Assume high current level (CCH) = 16A and low current level (CCL) = 0A. For a 41T0660, a 16A delta change in current represents less than 30% of full scale current this load module (< 18A). If the programmed slew rate is set to 0.1A/μs, the expected transition time would be:

$$Tr = \frac{0.8 * (16 - 0)}{0.1} \mu s = 128 \mu s$$

However, we determined that Tr_{min} for a slew rate of 0.1A/μs is at least 144 μs so the actual transition time will be limited to no less than 144 μs.

Maximum Tr

Use the following formula to calculate the maximum transition time for a given slew rate:

$$Tr_{max} = \frac{60(Max.Current)}{slew\ rate\ (A/\mu s)} * 0.8 \mu s$$

For a slew rate of 0.1A/μs, this results in:

$$Tr_{max} = \frac{60}{0.1} * 0.8 \mu s = 480 \mu s$$

Example 2:

Assume high current level (CCH) = 40A and low current level (CCL) = 0A. Since 40A represents more than 30% of the current range for the module used (40 > 18). If the slew rate is set to 0.1A/μs, the expected transition time would be:

$$Tr = \frac{0.8 * (40 - 0)}{0.1} \mu s = 320 \mu s$$

Since Tr_{max} for a slew rate of 0.1A/μs is 480 μs so the actual transition time will be lesser of these two values or 320 μs.

3.4 Current Read-back

The load current levels and load status can be set from the front panel of each load module or over the remote control interface. During testing, load input voltage and load current can be read back but the current read back will typically display the average current level unless the dynamic current frequency setting is low enough. An analog current monitor output is provided to allow capturing of dynamic current on a digital storage scope or data recorder.

3.5 Analog Input Mode

A set of analog inputs is provided at the rear panel of the mainframe to allow analog programming of load current using a function or arbitrary waveform generator. This allows any current profile within the performance envelope of the DC load to be used for perform dynamic load testing beyond the built in dynamic CC mode.

Note: This mode is supported in Constant Current (CC) and Constant Power (CP) modes only.

3.6 Product Features

The following key characteristics apply to all 41T Series modules.

- Fully programmable electronic DC load with flexible configuration and dual range capabilities.
- Full remote control of all load settings and metering read back.
- Dual high accuracy and high-resolution 5 digit voltage and current meters.
- Built-in pulse generator includes wide Thigh/Tlow dynamic load range, independent Rise/Fall load current slew rate control, and High/Low load level.
- Controllable load current slew rate of load level change,
- Load ON/OFF switch change and power supply turn ON.
- Short circuit test with current measure capability.
- Dedicated over current and over power protection test functions
- Automatic voltage sensing and external sense.
- Full protection from over power, over temperature, over voltage, and reverse polarity.
- Analog programming input
- Current monitor output signal (non-isolated)
- Variable fan speed control for quieter operation
- **Unique 41T Series Features:**
 - TURBO Mode provides 2 to 4 times rated current capability for up to 1 second durations.
 - MPPT Mode
 - Battery Management System (BMS) Test Functions
 - Current Protection Devices and Component Test modes
 - NTC Simulation for Lithium Battery Test (Requires NTC Option board)
 - Battery Test Modes Type 1 ~ 5
 - Battery Discharge Current Waveform (Requires CWG Option).

3.7 Accessories Included

The following accessories are included with each 41T Series DC Load in the quantities shown in the table below. If one or more of these items is missing upon incoming inspection of the product, please contact Adaptive Power Systems customer service.

Item	Description	41T
a	Banana plug, 4 mm, Red – Load connection	1
b	Banana plug, 4 mm, Black – Load connection	1
c	Banana plug, 2 mm, Red – V _{SENSE} connection	1
d	Banana plug, 2 mm, Black – V _{SENSE} connection	1
e	Y-hook Terminal, Large – Load connection	2
f	Y-hook Terminal, Small – V _{SENSE} connection	2
g	BNC Cable, 3 feet – I Monitor	1
h	Operator Manual PDF (download from www.adaptivepower.com)	1
i	Certificate of Conformance	1

Table 3-2: Included Accessories





Figure 3-3: 41T Series Accessories

3.7.1 Accessory Installation

Several connectors are included in the 41T ship kit to allow connection of load and sense wires to equipment unit under test (EUT). The following illustrations show how these connectors can be used to connect a load. Note that for lower impedance connections as may be desirable in high current applications, use of the banana jacks and Y-hooks (spade lugs) can be combined.

3.8 Interface Options

Refer to mainframe manual for list of available interface options.



4 Technical Specifications

Technical specifications shown here apply at an ambient temperature of 0 ~ 40° C°. Refer to V-I curve and Very Low Voltage V-I Curve charts by models for operating envelope.

4.1 Operating Ranges

MODEL	41T0630		41T0660		41T2512		41T5012		41T0615	
OPERATING RANGES										
Power Ranges	0-15 W	0-150 W	0-30 W	0-300 W	0-30 W	0-300 W	0-30 W	0-300 W	0-7.5 W	0-75 W
Current Ranges (TURBO)	0-3 A	0-30A (90A)	0-6 A	0-60A (180A)	0-1.2 A	0-12A (36A)	0-1.2 A	0-12A (24A)	0-1.5 A	0-15A (60A)
Voltage Range	60 V		60 V		250 V		500 V		60 V	
Load ON Voltage	0.1V ~ 25V		0.1V ~ 25V		0.2V ~ 50V		0.4V ~ 100V		0.1V ~ 25V	

MODEL	41T0880		41T5020		41T80160(M)		41T5040(M)	
Power Ranges (TURBO)	0-40 W	0-400 W (800 W)	0-40 W	0-400 W (800 W)	0-80 W	0-800 W (1600 W)	0-80 W	0-800 W (1600 W)
Current Ranges (TURBO)	0-8 A	0-80 A (160A)	0-2 A	0-20 A (40A)	0-16 A	0-160 A (320A)	0-2 A	0-40 A (80A)
Voltage Range	60 V		500 V		60 V		500 V	
Load ON Voltage	0.1V ~ 25V		0.4V ~ 100V		0.1V ~ 25V		0.4V ~ 100V	

4.2 Operating Modes

MODEL		41T0630		41T0660		41T2512		41T5012		41T0615	
OPERATING MODES											
CC Mode	Range	0-3 A	0-30 A	0-6 A	0-60 A	0-1.2 A	0-12 A	0-1.2 A	0-12 A	0-1.5 A	0-15 A
	Resolution	0.05mA	0.5 mA	0.1 mA	1 mA	0.02 mA	0.2 mA	0.02 mA	0.2 mA	0.0254 mA	0.25 mA
	Accuracy	± 0.1% OF (SETTING + RANGE)									
CR Mode	Range	2-120kΩ	0.02-2Ω	1-60kΩ	0.00833-1Ω	25-1500kΩ	0.08-25Ω	50-3000kΩ	0.5-50Ω	4-240kΩ	0.02-4Ω
	Resolution	0.00833mS	33.334μΩ	0.01666mS	16.667μΩ	0.000666mS	416.667μΩ	0.000333mS	833.334μΩ	0.04166mS	66.667μΩ
	Accuracy	± 0.2% OF (SETTING + RANGE)									
CV Mode	Range	0-6 V	0-60 V	0-6V	0-60V	0-30V	0-250 V	0-60 V	0-500 V	0-6 V	0-60 V
	Resolution	0.1 mV	1 mV	0.1 mV	1 mV	1 mV	10 mV	1 mV	10 mV	0.1 mV	1 mV
	Accuracy	± 0.05% OF (SETTING + RANGE)									
CP Mode	Range	0-15 W	0-150 W	0-30 W	0-300 W	0-30 W	0-300 W	0-30 W	0-300 W	0-7.5 W	0-75 W
	Resolution	0.25 mW	2.5 mW	1 mW	10 mW	1 mW	10 mW	1 mW	10 mW	0.125 mW	1.25mW
	Accuracy	± 0.5% OF (SETTING + RANGE)									
CC+CV Mode	Range	60 V	0-30 A	60V	0-60 A	250 V	0-12 A	500 V	0-12 A	60 V	0-15 A
	Resolution	1 mV	0.5 mA	1 mV	1 mA	0.01 V	0.2 mA	0.01 V	0.2 mA	1 mV	0.25 mA
	Accuracy	± 1.0% OF (SETTING + RANGE)									
CP+CV Mode	Range	60 V	0-150 W	60V	0-300 W	250 V	0-300 W	500 V	0-300 W	60 V	0-75 W
	Resolution	1 mV	2.5 mW	1 mV	5 mW	0.01 V	5 mW	0.01 V	5 mW	1 mV	1.25mW
	Accuracy	± 1.0% OF (SETTING + RANGE)									

MODEL		41T0880	41T5020	41T80160(M)	41T5040(M)
OPERATING MODES					
CC Mode	Range	0-8.04 A	0-80.4 A	0-2.04 A	0-20.4 A
	Resolution	0.134 mA	1.34 mA	0.034mA	0.34 mA
	Accuracy	± 0.1% OF (SETTING + RANGE)			
CR Mode	Range	1Ω-60kΩ	0.083-1Ω	30Ω-1800kΩ	0.03-30Ω
	Resolution	0.0166mS	0.0166mΩ	0.00055mS	0.5mΩ
	Accuracy	± 0.2% OF (SETTING + RANGE)			
CV Mode	Range	0-8.04 V	0-80.4 V	0-60V	0-500V
	Resolution	0.134 mV	1.34 mV	1 mV	10 mV
	Accuracy	± 0.05% OF (SETTING + RANGE)			
CP Mode	Range	0-40.02 W	0-400.2 W	0-40.02 W	0-400.2 W
	Resolution	0.667 mW	6.67 mW	0.667 mW	6.67 mW
	Accuracy	± 0.5% OF (SETTING + RANGE)			
CC+CV Mode	Range	80 V	0-80 A	500V	0-20 A
	Resolution	1.34 mV	1.34 mA	10 mV	0.34 mA
	Accuracy	± 1.0% OF (SETTING + RANGE)			
CP+CV Mode	Range	80 V	0-400 W	500V	0-800 W
	Resolution	0.134 mV	6.67 mW	10 mV	0.34 mA
	Accuracy	± 1.0% OF (SETTING + RANGE)			

4.3 Protection Modes

MODEL	41T0630	41T0660	41T2512	41T5012	41T0615
PROTECTION					
Over Power (OP)	157.5 W	315.0 W	315.0 W	315.0 W	78.75 W
Over Current (OC)	157.5 A	315.0 A	315.0 A	315.0 A	78.75 A
Over Voltage (OV)	31.5 V	63.0 V	12.6 V	12.6 V	15.75 B
Over Temperature (OT)	+85° C / +185° F				

MODEL	41T0880	41T5020	41T80160(M)	41T5040(M)
Over Power (OP)	420.0 W	420.0 W	840.0 W	840.0 W
Over Current (OC)	84.0 A	21.0 A	168.0 A	42.0 A
Over Voltage (OV)	84.0 V	525.0 V	84.0 V	525.0 V
Over Temperature (OT)	+85° C / +185° F			

4.4 Dynamic Operation Mode

MODEL	41T0630	41T0660	41T2512	41T5012	41T0615
DYNAMIC OPERATION					
T high & T low	50 μ s TO 9.999 s (20 kHz)				
Slew Rate	2.0-125 mA/ μ s	20-1250 mA/ μ s	4-250 mA/ μ s	40-2500 mA/ μ s	0.8-50 mA/ μ s
Accuracy	$\pm$ 5% OF SETTING $\pm$ 10 μ s				

MODEL	41T0880	41T5020	41T80160(M)	41T5040(M)
DYNAMIC OPERATION				
T high & T low	0.010~9.999 / 99./99 / 999.9 / 9.999 s (20 kHz)			
Slew Rate	5.4-337.5 mA/ μ s	54-3375 mA/ μ s	1.28-80 mA/ μ s	12.8-800 mA/ μ s
Accuracy	$\pm$ 5% OF SETTING $\pm$ 10 μ s			

4.5 Metering

Measurement specifications shown here apply at an ambient temperature of 25° $\pm$ 5° C. Refer to V-I curve and Very Low Voltage V-I Curve charts by models for operating envelope.

MODEL	41T0630	41T0660	41T2512	41T5012	41T0615
METERING					
Voltage Range	0 - 60.0 V	0 - 60.0 V	0 - 250 V	0 - 500.0 V	0 - 60.0 V
Resolution	1 mV	1 mV	1 mV	1 mV	1 mV
Accuracy	$\pm$ 0.025% OF (READING + RANGE)				
Current Range	0- 3.0 A	0- 30.0 A	0 - 6.0 A	0 - 60.0 A	0 - 1.2 A
Resolution	0.1 mA	1 mA	0.1 mA	1 mA	0.02 mA
Accuracy	$\pm$ 0.1% OF (READING + RANGE)				
Power Range	0-15 W	0-150 W	0-30 W	0-300 W	0-7.5 W
Resolution	0.1 W				
Accuracy	$\pm$ 0.125% OF (READING + RANGE)				

MODEL	41T0880	41T5020	41T80160(M)	41T5040(M)
METERING				
Voltage Range	0-80.4 V	0-500V	0-80.4 V	0-500V
Resolution	1.34 mV	10 mV	1.34 mV	10 mV
Accuracy	$\pm 0.025\%$ OF (READING + RANGE)			
Current Range	0-8.04 A	0-80.4 A	0-2.04 A	0-20.4 A
Resolution	0.134 mA	1.34 mA	0.034mA	0.34 mA
Accuracy	$\pm 0.1\%$ OF (READING + RANGE)			
Power Range	0-40.02 W	0-400.2 W	0-40.02 W	0-400.2 W
Resolution	0.1 W			
Accuracy	$\pm 0.125\%$ OF (READING + RANGE)			

4.6 Miscellaneous

MODEL	41T0630	41T0660	41T2512	41T5012	41T0615
SHORT CIRCUIT					
Typical Short Resistance	20 m Ω	8.3 m Ω	80 m Ω	0.5 Ω	20 m Ω
Max. Short Current	90 A	180 A	36 A	24 A	60 A
ANALOG I/O					
Analog Monitor Out	0 - 10 V out F.S. / 1K Ω Zout, Non-isolated				
Accuracy	$\pm 0.5\%$ OF (SETTING + RANGE)				
Analog Input (CCmode)	0 - 10V in for F.S. current @ 10V				

MODEL	41T0880	41T5020	41T80160(M)	41T5040(M)
SHORT CIRCUIT				
Typical Short Resistance	28.57 m Ω	0.3 Ω	4.15 m Ω	0.15 Ω
Max. Short Current	80 A	20 A	160 A	40 A
ANALOG I/O				
Analog Monitor Out	0 - 10 V out F.S. / 1K Ω Zout, Non-isolated			
Accuracy	$\pm 0.5\%$ OF (SETTING + RANGE)			
Analog Input (CCmode)	0 - 10V in for F.S. current @ 10V			

4.7 AC Input & Cooling

MODEL	All Models
AC INPUT AND COOLING SPECIFICATIONS	
AC Power	Supplied by 44M0XT Mainframe
Cooling	Supplied by 44M0XT Mainframe

4.8 Dimensions & Weight

4.8.1 Modules Loads

MODEL	Single Slot Modular Loads	41T80160M	41T5040M
DIMENSIONS AND WEIGHT			
Dimensions (H x W x D)	143 x 108 x 412 mm / 5.6" x 4.25" x 16.2"	143 x 216 x 412 mm / 5.6" x 9.5" x 16.2"	
Weight (Net)	3.7 kg / 8.2 lbs	7.4 kg / 16.4 lbs	

4.8.2 Bench Models

MODEL	41T80160	41T5040
DIMENSIONS AND WEIGHT		
Dimensions (H x W x D)	187 x 269 x 486 mm / 7.4" x 10.6" x 19.1"	
Weight (Net)	14.5 kg / 32.0 lbs	

4.9 Environmental



MODEL	All Models
ENVIRONMENTAL	
Operating Temperature	0 - 40° C / 32 - 104° F
Storage Temperature	-20 - 70° C / -4 - 158° F
Operating Relative Humidity	80% max. non-condensing
Storage Relative Humidity	< 90% RH
Environmental	Indoor Use Only, Pollution Degree 2
Altitude	2000 meter / 6500 feet max. Operating
EMC & Safety	CE Mark

4.10 Voltage versus Current Operating Envelope Charts



Following charts show constant power operating envelopes for each module. For operation at voltages below 1.0 Vdc, refer to the Low Voltage Operating charts. Operation below the red line shown in these charts is not specified.

Charts are shown by model on following pages.



4.10.1 Model 41T0630 V-I Curves





4.10.2 Model 41T0660 V-I Curves





4.10.3 Model 41T2512 V-I Curves





4.10.4 Model 41T5012 V-I Curves





4.10.5 Model 41T0615 V-I Curves





4.10.6 Model 41T0880 V-I Curves





4.10.7 Model 41T5020 V-I Curves



4.10.8 Model 41T08160 / 41T08160M V-I Curves



4.10.9 Model 41T5040 / 41T5040M V-I Curves



5 Unpacking and Installation

5.1 Inspection

The 41T Series DC loads are carefully inspected before shipment. If instrument damage has occurred during transport, please inform Adaptive Power Systems' nearest sales and service office or representative.

5.2 Load Module Installation and Removal in Mainframe

The 41T Series load modules must be installed in a suitable 44M0xT mainframe chassis to be used. The mainframe provides all required bias supply voltages as well as force air cooling of the load module(s).

Note: Older non-T version mainframes do **NOT** support 41T Load modules.

If ordered at the same time as a 44M0xT mainframe, the load modules on the same purchase order will be shipped already installed from the factory. If a load module requires installation or removal in the field, the end user can perform this task easily using the steps below.



5.2.1 Module Removal

1. First, ensure AC power to the 44M0X mainframe is switched **OFF**. Failure to do so may result in damage to the load module. The load modules are NOT hot-swappable.
2. Loosen and completely remove the Phillips screw in the lower right hand corner of the load modules front panel. This screw prevents the load module from sliding out of its slot position.
3. Once the screw is removed, the handle can be pulled forward to level the module out of its back plane connectors.
4. Once the level has been pulled as far as it will go, the module can be slid out carefully by pulling it forward until it completely clears the mainframe front bezel.

Refer to Figure 5-1 on next page for an illustration.




Figure 5-1: Load Module Removal

5.2.2 Module Installation

To install a new or different module in an available slot, follow the removal procedure in reverse order.

5.3 Cleaning

To clean this product use a soft or slightly damp cloth.



CAUTION

BEFORE you clean the unit, switch the mains power off and disconnect the input line cord.

- Please do NOT use any organic solvent capable of changing the nature of the plastic such as benzene or acetone.
- Please ensure that no liquid is allowed to penetrate this product.

5.4 Powering Up

The following procedure should be followed before applying mains power:

1. Check that the POWER switch is in the OFF (O) position.
2. Verify that the rear panel voltage selector of the chassis is correctly set.
3. Check that nothing is connected to any of the DC INPUT (load input terminals) on the front and/or rear panels.
4. Connect the correct AC mains line cord to the 41T Series load AC input terminal.
5. Plug the line cord plug into a suitable AC outlet socket.
6. Turn on (I) the POWER switch.
7. If the instrument does not turn on for some reason, turn OFF the POWER switch and verify the presence of the correct AC line input voltage using appropriate safety measures.

5.5 In Case of Malfunction

In the unlikely event of an instrument malfunction or if the instrument does not turn on despite the presence of the correct AC line voltage, please attach a warning tag to the instrument to identify the owner and indicate that service or repair is required. Contact Adaptive Power Systems or its authorized representative to arrange for service.

5.6 Load Connections



WARNING

DO NOT EXCEED LOAD INPUT VOLTAGE RATING

This instrument does **NOT** have a means to disconnect its Load input from a connected power supply. If the voltage applied to the Load input exceeds its maximum rating – even if the load is turned completely off – damage to the load **WILL** occur. Damage caused by exceeded maximum load input voltage under any circumstance is **NOT** covered by the manufacturer's product warranty. Remove any load input connections when the load is not in use, even when it is turned off.

When setting up for a new test and connecting any equipment to the DC load, proceed as follows:

1. Always make sure the DC load is turned OFF at the POWER switch when making any wire connections.
2. Check that the output of the equipment under test is **OFF**.
Note: Some power equipment's output may still be energized even if the equipment has been turned off or its output is turned off. This is especially true for DC power supplies.

Note: When working with batteries, it is recommended to provide a suitable disconnect relay or switch so the load connection can be disconnected from the battery for handling purposes.
3. Connect one end of the load wires to the load input terminals on the rear panel.
4. Check the polarity of the connections and connect the other end of the load wires to the output terminal of the equipment under test.
5. When connecting multiple loads to the same EUT, make sure the load wire lengths to each load are the same.

5.7 Analog Programming Input

The 41T Series has an analog programming input located on the rear panel of the **44M0xT** model mainframe. This feature allows an external waveform to be tracked as long as it is within the load's dynamic capabilities. These inputs will accept a 0-10V signal. This signal is proportional to the load's maximum current range.




Figure 5-2: Location and Pin-out of Analog Programming Input Connector

Channel positions are numbered from left to right when facing the front of the mainframe as shown in the illustration below.




Figure 5-3: Channel Positions for Analog Input Identification

The analog programming input operates in CC or CP modes only. The load module will attempt to load proportionally according to the signal and the load module's maximum current or power range.

For example: $I_{max} = 60A$ and $P_{max} = 300W$

- In CC mode, if the analog programming input is 5V, the load current will be $0.5 \times 60 = 30A$.
- In CP mode, if the analog programming input is 1V, the load power setting will be $0.1 \times 300 = 30W$.

The analog programming signal can act alone or it can be summed with the programmed value set via the front panel or the optional computer interface (GPIB, RS232, USB, or LAN).

Figure 5-4 shows the result of an analog programming signal at 4Vpp, 500Hz when it is summed with a 24A programmed setting in CC mode of DC load.




Figure 5-4: Analog Programming Example

5.8 Load Current Slew Rate

The programmable current slew rate of the DC load allows control over the rate of change in current any time a change in current occurs. This controls the load current slew rate during load current level changes, power supply turn ON/OFF events or when turning the LOAD ON, and OFF. The 41T Series loads provide controlled current slewing under all of these conditions. The rise and fall current slew rate can each be set independently.

Rise and fall slew rates can be independently programmed. This allows an independent controlled transition from Low load current level to High load current level (Rise current slew rate) or from High load current level to Low load current level(Fall current slew rate) to minimize induced voltage drops on the wiring inductance, or to control induced voltage transients on the device under test (power supply transient response testing).

See under "DYNAMIC OPERATION, Slew Rate" in the specification section on page 24 for slew rate programming range by model.

This controllable load current slew rate feature also can eliminate the overload current phenomenon and emulate the actual load current slew rate at turn ON of the power supply under test. Figure 5-5 shows the load current slew rate is according to the power supply's output voltage, load level setting and Load ON/OFF switch.

The ability to apply all these dynamic current characteristics at the same time using the Constant Current mode of the 41T Series load greatly speeds up power supply testing tasks. This can significantly improve the test quality, thoroughness and efficiency.

There are two load current ranges in 41T Series Load, Range I and Range II, the rise and fall slews rate range for both current ranges is specified in Section 4.1, “ ” on page 24.




Figure 5-5: Effect of Current Slew Rate Settings on Power Supply Testing

6 Front Panel Operation

This Chapter provides an overview of front panel operation for the 41T Series DC Loads. For remote control operation, refer to Section 10 "" of this manual for an overview of available programming commands.

6.1 Front Panel Layout

The front panel layout is shown in Figure 6-1 below.



Figure 6-1: 41T08160 Load Front Panel View

Each load or load module has its own dedicated LCD readouts located along the top. User controls are located below these displays. Along the bottom edge, memory bank controls are positioned next to a separate memory bank and system setting display. The power ON/OFF switch is found in the lower left corner.

6.2 User Controls and Readouts

The following user controls, indicator and displays are common to all 41T Series load models. The purpose and function of each control and indicator is explained in the table below. Refer to figure for the location of each control and indicator.

-
1. Model Number and ranges
 2. Go/NoGo indicator illuminates if upper or lower limit settings are exceeded.
 3. Operating Mode Indicators
 4. REMOTE state indicator
 5. Multi-purpose 5 digit display - Voltage
 6. Multi-purpose 5 digit display - Current
 7. Multi-purpose 5 digit display - Power
 8. MODE selection key
 9. LOAD ON/OFF button and indicator
 10. DYNAMIC mode button and indicator
 11. High or Low Range Selection and indicator
 12. High or Low Level setting selection and indicator
 13. Preset Mode ON/OFF
 14. Limit Setup Menu
 15. DYNAMINC Mode settings
 16. Configuration Menu
 17. Short Circuit Test key and indicator
 18. OCP (Over Current Protection) Test key and indicator
 19. OPP (Over Power Protection) Test key and indicator
 20. SHORT, OCP & OPP Start/Stop
 21. Shuttle Knob, parameter selection, slew and cursor keys
 22. Load Input connectors
 23. External Voltage sense input connectors
 24. I-Monitor output BNC connector
 25. Module mounting screw
 26. FUSE Test Menu
 27. BMS Battery Management System Menu

Figure 6-2: Front Panel User Controls and Indicators

The various controls and indicators are explained in more detail in the table below. The Item numbers correspond to the indices in Figure above.

KEY#	Description
1	Indicates the model number and key performance specifications of the load.
2	Go/NoGo indicator illuminates if upper or lower limit settings are exceeded.
3	There are four operating modes can be selected by pressing the "MODE" key on the electronic load. The sequence is Constant Current (CC), Constant Resistance (CR), Constant Voltage (CV), Constant Power (CP) and then repeats. When pressing the "MODE" key, the CC, CR, CV, CP mode indicator will be lit respectively when the appropriate operating mode is selected. The operating theorem of CC, CR, CV and CP mode is described in Section 3.2, "Operating Modes". There are two programming ranges in CC, CR, CV and CP mode respectively; the 41T Series load can adjust to the optimal range automatically according to the programmed load level. The range selection criteria are described below for each operating mode.

KEY#	Description
	CC Mode The Range I (6A) indicates low load current operating range; Range II (60A) indicates high load current operating range. The specification of load current ranges is listed in Section 4.1. The current range is changed automatically in accordance to the programmed load current. Range I is selected automatically if the programmed load current is less than the maximum current of Range I, and will be set to Range II automatically when the programmed current is higher than the maximum current of Range I.
	CR Mode Range I indicates low load resistance operating range, Range II indicates high load resistance operating range. The specification of the resistance ranges is shown in section 4.1, "Operating Ranges". The resistance range is changed automatically in accordance to the programmed load resistance. The electronic load will switch to Range I automatically if the programmed load resistance is higher than the minimum load resistance of Range I, and will be set to Range II when the programmed load resistance is lower than the minimum load resistance of Range I.
	CV Mode Range I indicates low load voltage operating range, Range II indicates high load voltage operating range. The specification of voltage ranges is shown in section 4.1, "Operating Ranges". The voltage range is changed automatically in accordance to the programmed load voltage. Range I is selected automatically if the programmed load voltage is less than the maximum voltage of Range I (6V), and will be set to range II automatically when the programmed voltage is higher than the maximum voltage of Range I (6V).
	CP Mode Range I indicates low load power operating range, Range II indicates high load power operating range. The power range specification is shown in section 4.1, "Operating Ranges". The power range is changed automatically in accordance with the programmed load power. Range I is selected automatically if the programmed load power is less than the maximum power of Range I (120W), and will be set to Range II automatically when the programmed power is higher than the maximum power of Range I (120W).
4	The Remote LCD Indicator is used to indicate the status of remote operation. Front panel operation is locked out while the remote LCD annunciator is ON. In case of Local mode or manual operation, the Remote LCD annunciator is OFF






KEY#	Description
5	The 5 digit LCD display is a multi-function display, the functions are described below: Normal mode: This is a 5 digit DVM display, measuring data of the DC input terminal or V-sense input terminal if V-sense AUTO is programmed. If V-sense ON is programmed, the display shows the voltage at the V-sense input terminal only. When the auto-sense of V-sense function is programmed, the auto-sense circuit of the electronic load can check if the V-sense cable is connected, If the V-sense input detected is greater than 0.7V (e.g. 5L12-24,) or not. If both conditions are true, the 5 digit DVM measures at the sense input (remote V sense); otherwise, the 5 digit DVM measures at the DC input terminals of the load (local V sense). Test Setting Mode: Short: Short test Enable and Short Setting programming: Display will show: "Short". OPP: OPP test Enable and OPP Setting programming: Display will show: "OPP". OCP: OCP test Enable and OCP Setting programming: Display will show: "OCP". During Short, OCP and OPP test programming, this display will show sensed voltage or load Input voltage.
6	This readout can be in one of two modes: Normal or Setting mode. In "Normal" mode, this 5 digit LCD displays the measured current of the DC load when the load is ON. In "Setting" mode, this LCD displays the following setting parameters. The rotary knob is used to scroll through these settings: 1. Config ON programming: Display will individually show "SENSE", "LDon", "LDOFF", "POLAR", "MPPT" and "AVG". 2. Limit ON programming: Display will individually show "V_Hi", "V_Lo", "A_Hi", "A_Lo", "W_Hi", "W_Lo" and "NG". 3. DYN setting ON programming: Display will individually show "T-Hi", "T-Lo", "RISE" and "FALL". 4. Short setting programming: Display will individually show "TIME", "V-Hi" and "V-Lo". 5. OPP setting programming: Display will individually show "PSTAR", "PSTEP", "PSTOP" and "VTH". 6. OCP setting programming: Display will individually show "ISTAR", "ISTEP", "ISTOP" and "VTH". During Short testing: Display shows the actual load current, the unit is "A". During OCP testing: Display shows the actual load current, the unit is "A". During OPP testing: Display shows the actual power, the unit is "W". When over current protect is tripped: Display shows [OCP].
7	This readout can be in one of two modes: Normal or Setting mode. In "Normal" mode, this 5 digit LCD displays the power dissipated by the DC load when the load is ON.



KEY#	Description
	In "Setting" mode, this LCD displays the following setting parameters. The rotary knob is used to scroll through these settings: - PRESET ON mode display will individually show: - CC mode's current programming value display, the unit is "A" - CR mode's resistor programming value display, the unit is "Ω" - CV mode's voltage programming value display, the unit is "V" - CP mode's power programming value display, the unit is "W" - LIMIT ON mode display will individually show : - V_Hi (upper limit voltage) & V_Lo (lower limit voltage) value display, the unit is "V" - A_Hi (upper limit current) & A_Lo (lower limit current) value display, the unit is "A" - W_Hi (upper limit power) & W_Lo (lower limit power) value display, the unit is "W" - NG programming display will show [ON] or [OFF] - DYN setting ON mode display will individually show : - T-Hi (level high time) & T-Lo (level low time) programming value display, the unit is "ms" - Rise/Fall current slew rate programming value display, the unit is "(m)A/us" - Config ON mode display will individually show: - SENSE programming display shows [ON] or [AUTO] - LDon & LDoff value displayed, the unit are "V" - Load polarity value display shows [+LOAD] or [-LOAD] - Short test Enable, OCP test Enable and OPP test Enable mode will show [START] - Short Setting mode - Short setting display will show "CONTI", Short time setting; the unit is "ms" - V-Hi & V-Lo value display, the unit is "V" - OPP Setting mode - OPP PSTAR, OPP PSTEP and OPP PSTOP value display, the unit is "W" - OPP Vth value display, the unit is "V". - OCP Setting mode - OCP ISTAR, OCP ISTEP and OCP ISTOP value display, the unit is "A" - OCP VTH value display, the unit is "V" During OCP test & OPP test, display will show [RUN] When over power protect: Display will show [OPP] When over temperature protect: Display will show [OTP]
8	MODE and CC, CR, CV, CP Indicator There are four operating modes that can be selected by pressing the "MODE" key. The sequence is Constant Current (CC), Constant Resistance (CR), Constant Voltage (CV), Constant Power (CP) and then repeats while pressing the "MODE" key. The CC, CR, CV or CP mode indicator will be lit respectively when the appropriate operating mode is selected.

KEY#	Description
9	LOAD ON/OFF key and LED The load input can be toggled ON/OFF using the front panel's LOAD ON/OFF key. The load current slew rate follows the slew rate setting, so the load current slew rate will change at the programmed Rise/Fall slew rate setting respectively. Turning the LOAD OFF does not affect the programmed settings. The LED is OFF to indicate LOAD OFF status. The LOAD will return to the previously programmed values when the LOAD key is turned to ON again. The Load ON LED indicates the load is ready to sink current from DC input. 1. Load ON/OFF key: Switches from load ON to load OFF. The fall slew rate is in accordance with the slew rate setting on the front panel. 2. DC input voltage: There is a load ON and load OFF voltage control circuit in the electronic load. When the Device under Test turns ON, the output voltage of D.U.T will increase up from 0 to rated output voltage. The electronic load will start to sink current after load voltage is higher than load ON voltage configuration setting (See "Config" key). The programmed load ON voltage for the 41T Series load is from 0.1 to 25V. When the device under test (DUT) turns OFF, the output voltage of DUT will decrease down to 0 volt. The electronic load will stop to sink current after load voltage is lower than load OFF voltage configuration setting (See "Config" key). The programmed load OFF voltage for the load is from 0 Vdc to the load ON voltage value.
10	DYN / STA key and LED This key is available in Constant Current and Constant Power mode only. In Constant Resistance and Constant Voltage mode, this key has no function and the LED is OFF. The load will default to static mode. In Constant Current and Constant Power mode, the Static or Dynamic mode is toggled by this key; the LED will be lit if the load is in Dynamic mode.
11	RANGE key and LED RANGE AUTO / II Key is for range selection. If the Range AUTO LED is OFF, the load will be in Range I or II in accordance with the actual current value. When Range the II, LED is ON, the current programming will be locked on Range II.

KEY#	Description
12	LEVEL key and LED The LEVEL key is used to toggle between the High and Low load setting value. This applies in static mode only. In the Dynamic Constant Current mode, the High and Low level are used to define levels of the dynamic waveform. 1. In Constant Current mode: The level is initially set to High. LEVEL High / Low has two levels, Low current level setting must be lower than Level High. 2. In Constant Resistance mode: The level is initially set to High. LEVEL High / Low has two levels, Low resistance level setting must be higher than Level High. Note: CR Mode Level High / Low level by current perspectives. 3. In Constant Voltage mode: The level is initially set to High. LEVEL High / Low has two levels, Low voltage level setting must be lower than Level High. Note: CV Mode Level High / Low has "automatic push function." 4. In Constant Power mode: The level is initially set to High. LEVEL High / Low has two levels, Low power level setting must be lower than Level High. Note: Automatic level function: The High level setting must be higher or equal than Low level setting. When High level is equal to Low level, no further adjustment is possible. When the High level equals the Low level, the Automatic level function will adjust the Low level value so the High level value can continue to be adjusted.
13	PRESET ON/OFF key and LED In PRESET OFF state, the load input voltage is shown on the upper 5-digit meter, and load input current is shown on the middle 5-digit meter. The load input power is shown on the lower 5-digit meter. The engineering unit "V", "A" and "W" LCDs will be lit respectively. In Preset ON state, the PRES. LED is ON, the lower 5-digit meter display will be determined by the CC, Dynamic, CR, CV, and CP operating mode. In Preset ON condition, the 5 digit DAM indicates the set load current, which can be from front panel or remote control interface setting. 1. In Constant Current mode: The High / Low level load current value can be preset on the lower 5 digit LCD display. The unit is "A" and the "A" will be lit as well. 2. In Dynamic load mode: The High / Low parameters value of High / Low load current duration and Rise / Fall setting can be displayed on the lower 5 digit LCD display. The unit is "ms" and the "ms" will be lit as well. 3. In Constant Resistance mode: The High / Low level load resistance value can be preset on the lower 5 digit LCD display. The engineering unit is "Ω" and the "Ω" will be lit as well. 4. In Constant Voltage mode: The High / Low level load voltage value can be preset on the upper 5 digit LCD display. The unit is "V" and the "V" will be lit as well. 5. In Constant Power mode: The High / Low level load power value can be preset on the upper 5 digit LCD display. The unit is "W" and the "W" will be lit as well.


KEY#	Description
14	LIMIT key and LED The LIMIT key setting includes the GO/NG check of digital voltage meter Upper/Lower limit, current meter Upper/Lower limit, and watt meter Upper/Lower limit within the Limit key setting. The setting sequence is shown below: OFF ⇒ DVM Upper/Lower limit ⇒ DAM Upper/Lower limit ⇒ DWM Upper/Lower limit ⇒ GO/NG check ON/OFF ⇒ OFF ⇒ Repeat The screen images below show the sequence of screens and parameters available to set on each screen. For additional information on using the NG mode, refer to section 6.6, "Go/NoGo LIMIT Testing".

KEY#	Description
	Setting Upper limit voltage V_{Hi}: Middle 5 digit LCD displays [V_{Hi}], lower 5 digit LCD displays the unit in "V". The V_{Hi} set range is from 0.000V to 60.000V. Adjust in 0.001V steps by rotating the dial. 
	Setting lower limit voltage V_{Lo}: Middle 5 digit LCD displays [V_{Lo}], lower 5 digit LCD displays the unit in "V". The V_{Lo} set range is from 0.000V to 60.000V. Adjust in 0.001V steps by rotating the dial. 
	Setting Upper limit current I_{Hi}: Middle 5 digit LCD displays [I_{Hi}], lower 5 digit LCD displays the unit in "A". The I_{Hi} set range is from 0.000A to 60.000A. Adjust in 0.001A steps by rotating the dial. 
	Setting lower limit current I_{Lo}: Middle 5 digit LCD displays [I_{Lo}], lower 5 digit LCD displays the unit in "A". The I_{Lo} set range is from 0.000A to 60.000A. Adjust in 0.001A steps by rotating the dial. 
	Setting Upper limit power W_{Hi}: Middle 5 digit LCD displays [W_{Hi}], lower 5 digit LCD displays the unit in "W". The W_{Hi} set range is from 0.00W to 300.00W. Adjust in 0.01W steps by rotating the dial. 

KEY#	Description
	Setting lower limit power W_Lo: Middle 5 digit LCD displays [W_Lo], lower 5 digit LCD displays the unit in "W". The W_Lo set range is from 0.00W to 300.00W. Adjust in 0.01W steps by rotating the dial. 
	Setting NG ON/OFF: When NG is turned on (turn dial for On or OFF), a NG indication will be displayed when any of the set measurement limits is exceeded. 
15	DYN setting key and LED DYN setting key is to set the Dynamic Mode parameters. They are rise, fall, Thigh and Tlow. Parameters can be changed using the rotary knob. Press any key to escape the DYN parameter setting mode. 1. Press DYN setting key, LED will turn ON 2. Setting level High Period: Middle 5 digit LCD display will show "T-Hi", left 5 digit LCD display will show setting value. The unit is "ms" 3. Setting level Low period: Middle 5 digit LCD display will show "T-Lo", left 5 digit LCD display will show setting value. The unit is "ms" 4. Setting rise time: Middle 5 digit LCD display will show "RISE", left 5 digit LCD display will show setting value. The unit is "(m)A/us" 5. Setting fall time: Middle 5 digit LCD display will show "FALL", left 5 digit LCD display will show setting value. The unit is "(m)A/us" The screen images below show the sequence of screens and parameters available to set on each screen. For additional information on using the DYNAMIC mode, refer to section 0, "The CC+CP mode is a combination of constant current and the constant power modes and is also intended for battery test applications. When the load is used in constant current mode, it is possible to add CP mode as well by selecting the add.CP setting. This mode operates in a similar fashion as the CC+CV mode but operates in a constant power mode until the power exceeds the power setting at which point the load transitions to constant voltage mode of operation. Static versus Dynamic Operating Modes".


KEY# Description




The time during which the waveform is high includes the rise time and is set in “ms”. The time during which the waveform is low includes the fall time and is set in “ms”. The RISE and FALL times are set in “mA/μs” or “A/μs”. The actual engineering unit is shown in the bottom right corner of the LCD display.








To program the Dynamic mode, proceed as follows:

Press DYN setting key. The DYN LED will turn ON. To set the T_Hi high level period, the middle 5 digit LCD display will show [T-Hi]. The lower 5 digit LCD display will show the set value in “ms”. The T_Hi set range is from 0.050 ms to 9999 ms. Adjust in 0.001ms steps by rotating the dial.



KEY#	Description
	To set the T_{Lo} high level period, the middle 5 digit LCD display will show [T-LO]. The lower 5 digit LCD display will show the set value in “ms”. The T_{Lo} set range is from 0.050 ms to 9999 ms. Adjust in 0.001ms steps by rotating the dial. 
	To set the RISE time, the middle 5 digit LCD display will show [RISE]. The lower 5 digit LCD display will show the current slew rate in “mA/μs”. The slew rate range is from 4mA/μs to 255mA/μs. Adjust in 1mA/μs steps by rotating the dial. 
	To set the FALL time, the middle 5 digit LCD display will show [FALL]. The lower 5 digit LCD display will show the current slew rate in “mA/μs”. The slew rate range is from 4mA/μs to 255mA/μs. Adjust in 1mA/μs steps by rotating the dial. 

KEY#	Description
16	CONFIG key and LED The CONFIG key setting includes the Sense AUTO/ON, Load ON/OFF voltage, Load Polarity, MPPT tracking and measurement averaging. Each press of the CONFIG key moves the menu one step. On the first press of the CONFIG key, the CONFIG button will illuminate and SENSE will be displayed on the middle LCD. The value is adjusted with the dial and can be read from the lower LCD during setting. The setting sequence is shown below. SENSE AUTO/ON ⇒ Load ON/OFF Voltage ⇒ Polarity setting ⇒ MPPT ⇒ AVG ⇒ Exit  Notes: 1. The adjustable LOAD ON voltage (LD ON) is valid for CC, CR & CP operating modes only. It does not operate in CV mode. 2. The LOAD ON voltage setting cannot be lower than the LOAD OFF voltage setting. If 0V is required for both LOAD ON and LOAD OFF, make the LOAD OFF adjustment first.

KEY#	Description						
	Setting the Vsense mode: Press the CONFIG key. The middle 5 digit LCD display will show "SENSE". The lower 5 digit LCD display will show "AUTO" or "ON". Use the rotary dial to toggle the setting. 						
	Setting the LOAD ON voltage levels: Press the CONFIG key twice. The middle 5 digit LCD display will show "LDon". The lower 5 digit LCD display will show the set value in Volts. The Load ON Voltage set range varies by 41T model: <table> <tr> <td>41T0615 ,41T0630, 41T0660</td><td>0V to 25V in 0.1V steps</td></tr> <tr> <td>41T2512</td><td>0V to 50V in 0.2V steps</td></tr> <tr> <td>41T5012</td><td>0V to 100V in 0.5V steps</td></tr> </table> Adjust by rotating the dial. If the input voltage to the load is greater than the Load ON voltage setting, the load starts to sink current. 	41T0615 ,41T0630, 41T0660	0V to 25V in 0.1V steps	41T2512	0V to 50V in 0.2V steps	41T5012	0V to 100V in 0.5V steps
41T0615 ,41T0630, 41T0660	0V to 25V in 0.1V steps						
41T2512	0V to 50V in 0.2V steps						
41T5012	0V to 100V in 0.5V steps						
	Setting the LOAD OFF voltage levels: Press the CONFIG key till the LOAD OFF screen appears. The middle 5 digit LCD display will show "LDOFF". The lower 5 digit LCD display will show the set value in Volts. The Load OFF Voltage set range varies by 41T model: <table> <tr> <td>41T0615 ,41T0630, 41T0660</td><td>0V to 24.9V in 0.1V steps</td></tr> <tr> <td>41T2512</td><td>0V to 49.8V in 0.2V steps</td></tr> <tr> <td>41T5012</td><td>0V to 99.5V in 0.5V steps</td></tr> </table> Adjust by rotating the dial. If the input voltage to the load is lower than the Load OFF voltage setting, the load turns off. 	41T0615 ,41T0630, 41T0660	0V to 24.9V in 0.1V steps	41T2512	0V to 49.8V in 0.2V steps	41T5012	0V to 99.5V in 0.5V steps
41T0615 ,41T0630, 41T0660	0V to 24.9V in 0.1V steps						
41T2512	0V to 49.8V in 0.2V steps						
41T5012	0V to 99.5V in 0.5V steps						
	Setting the Load polarity: Press the CONFIG key till the POLARITY screen appears. The middle 5 digit LCD display will show "POLAR". The lower 5 digit LCD display will show "+ LOAD" or "-LOAD". Use the dial to toggle between "+ LOAD" or "-LOAD" settings. 						

Setting MPPT time interval: Press the CONFIG key till the MPPT screen appears. The middle 5 digit LCD display will show "MPPT". The lower 5 digit LCD display will show the MPPT interval time in msec. This value is the time between recordings on MPP voltage, current and power to internal memory. The internal memory buffer can hold up to 720 recordings. The MPPT setting range is from 1000ms to 60000ms in 1000ms steps. Adjust by rotating the dial. When the internal buffer is full MPP recording stops automatically. The memory buffer is erased when the load is powered off.

6.3 For more information on using the MPPT operation mode, refer to section 6.7, "TURBO Mode"

This mode allows the load to support up to four times the rated current and power of a 41T Series load for short periods of time.

Turbo mode is very valuable for enhanced protection testing of power products. Examples include power supplies, Battery Management Systems (BMS) and protection devices such as Fuses / Breakers or PTC Resettable fuses. In so doing, the 41T Series can test and verify the actual trip current levels and response times under the abnormal operating conditions.

The following example illustrates the ease of performing these kinds of test with the 41T Loads.

1. Turbo mode ON/OFF indicator, Turbo mode includes Short, OCP, OPP, BMS and Fuse test functions, the others new functions are MPPT with CC and CR mode, CV response time setting, Battery discharge Batt1 ~ Batt3 in Config key.
2. Fuse (Current Protection Components) Test function key.
3. BMS (Battery Management System) test mode key.
4. Add CC+CV and CP+CV for battery discharge test.

In addition to the Turbo mode, the 41T loads also support NTC resistor simulation, which is an option on the 44M0xT series mainframe. These load functions support of a wide range of battery discharge testing. Particularly useful for these applications are the new CC + CV and CP + CV operation modes, battery discharge capacity test and dynamic cycle discharge test.

See subsequent sections for more details.

6.4 Power Supply Overload Testing

This function applies to AC/DC, DC/DC Power Supplies, DC/AC inverters, Power Adapters and Device Chargers. These products are not only designed to supply a stable voltage or current, they also need to protect load against abnormal conditions in order to ensure safe operation under all conditions. They are to

prevent overheating or high temperature due to excessive current, which could result in a fire and other hazards.



Short circuit, Over Current and Over Power are all abnormal conditions. These conditions typically represent 125% to 150% of the normal rating and in some cases even more. Therefore, to simulate these abnormal conditions, the maximum current value and the maximum power value of the electronic load to perform these tests must be up to two times the normal rating. One solution is do use a load that is twice as big as needed for normal testing but this will cost more. A better alternative is to use the 41T Series loads, which can provide up to four times rated power and current conditions with a 'normal' rated model. The table below illustrates the capabilities of each 41T model load in this application.


Model		41T0630	41T0660	41T2512	41T5012	41T10012
Short / OCP / OPP Function						
Max. Current	TURBO OFF	30 A	60 A	12 A	12 A	
	TURBO ON	90 A	180 A	36 A	24 A	
Measurement Accuracy		± 1.0% (Reading + Range)				
Short Time	TURBO OFF	100 msec ~ 10 Sec. or Continuous				
	TURBO ON	100 ~ 1000 msec				
OCP Time (Tstep)	TURBO OFF	100 ms				
	TURBO ON	20 ms				
OPP Time (Tstep)	TURBO OFF	100 ms				
	TURBO ON	20 ms				

Table 6-2: Short / OCP / OPP Capabilities


The power supply products under test must respond with the appropriate protection function but the abnormal situation duration is often quite short. To test for these conditions, the 41T Series electronic load can increase the electronic load current and power in the new Turbo mode some period of time (within 1 second) up to 2 to 4 times the rated value. For example, the 41T0660 60V / 60A / 300W load in Turbo mode can increase its load current to 180A or power to 900W electronic load for up to one second. When verifying power products using Turbo mode in a production test environment, the 41T Series electronic loads offer greater test verification capability compared to conventional DC loads. Furthermore, the 41T Series built-in measurement circuits can also measure the actual trip current value and protection response time under short-circuit or overload test conditions.

Examples of using Turbo mode for these tests are shown on next few pages.


6.4.1 SHORT Test Mode in Normal and Turbo Mode





6.4.2 Over Current Protection Mode in Normal and Turbo Mode



6.4.3 Over Power Protection Mode in Normal and Turbo Mode






MPPT Mode".

KEY#	Description
	 Note: This function requires firmware revision r1.1 or higher. Setting AVERAGING: Press the CONFIG key until the AVERAGE screen appears. The middle 5 digit LCD display will show "AVG". The lower 5 digit LCD display will show the AVERAGING count. The averaging range is from 1 (default) to 64 in 1 increments. Adjust by rotating the dial. Averaging of measurements results in more stable readings but slows down the measurement update rate. If averaging is required, chose a setting that best balances stability of readings with update rate.  Note: This function requires firmware revision r2.05 or higher.

KEY#	Description
17	SHORT key and LED Functions - Short test function Enable/Disable Key: Press the “SHORT” key to enable the short test function. The indicator LED will be lit. The LCD display shows “SHORT” on the upper 5-digit LCD display, shows “PRESS” on the middle 5-digit LCD display and shows START” on the lower 5-digit LCD display. - Short test function parameter setting key: There are three parameters for the SHORT test function. The parameters are: TIME, V-Hi and V-Lo. Press the “SHORT” key again to set short test time when the SHORT test function is enabled. Press SHORT key again to proceed to the next parameter and follow the sequence of TIME, V-Hi, V-Lo and Disable. Press any another key to exit and save the SHORT settings. The SHORT test parameter descriptions are as follows: - TIME: Setting the short test time. The LCD display shows “SHORT”, “TIME” and CONT (or initial setup value) on the top to bottom 5-digit LCD displays. The setting range is “CONTI” which means continuous or 100ms to 10000ms in 100ms steps. Turn the rotary knob clockwise to adjust this the setting. The short test will have no time limitation when set to “CONTI” until the “START/STOP” key is pressed to stop the short test. - V-Hi: Short test voltage check upper limitation setting. The LCD displays show “SHORT”, “V-Hi” and 0.00V (or initial setup value) from top to bottom. The V-Hi setting range is from 0.00 to 60.00V in 0.01V steps and can be adjusted by turning the rotary knob. - V-Lo: Short test voltage check lower limitation setting. The LCD displays show “SHORT”, “V-Lo” and 0.00V (or initial setup value) from top to bottom. The V-Lo setting range is from 0.00 to 60.00V in 0.01V steps and can be adjusted by turning the rotary knob. Note: The V-Hi and V-Lo parameters of the SHORT test are different from the V-Hi and V-Lo settings of the LIMIT function. - START/STOP Test key. Press the “START/STOP” key to start or stop the SHORT test when SHORT test function is enabled. The Load will go to “ON” state automatically when the “START/STOP” key is pressed and start the SHORT test. The Load will go to “OFF” state automatically when the “START/STOP” key is pressed to stop the short test. However, the Load will stay in the “ON” state if the load was “ON” before SHORT test execution. The SHORT test function is used to the UUT’s short circuit protection function. The SHORT test will sink the load’s full scale current until the UUT’s voltage drop is between the set V_Hi and V_Lo limits. The lower 5-digit LCD display will shows “PASS”, otherwise it will show “FAIL”. Press any key to return to normal mode LCD display.

KEY#	Description
18	OCP key and LED Functions - OCP test function Enable/Disable Key. Press the “OCP” key to enable the OCP test function and the indicator LED will be lit. The LCD display shows “OCP” on right 5-digit LCD display, shows “PRESS” on the middle 5-digit LCD display and shows “START” on left 5-digit LCD display. - OCP test function parameter settings. There are four parameters for the OCP test function. These parameters are: ISTAR, ISTEP, ISTOP and Vth. Press the “OCP” key again to set the OCP test parameter ISTAR(start current point) Press the “OCP” key again to proceed to the next parameter in order of ISTEP, ISTOP, Vth and Disable. Press any another key to exit the and save the OCP settings. The OCP test parameter descriptions are as follows: - ISTAR: Setting the start current point. The LCD display shows “OCP”, “ISTAR” and 0.000A (or initial setup value) from top to bottom on the 5-digit LCD displays. The setting range is 0.000A to the full scale of the CC mode specification. This parameter can be adjusted by turning the rotary knob. - ISTEP: Setting the increment current step size. The LCD display shows “OCP”, “ISTEP” and 0.000A (or initial setup value) from top to bottom on the 5-digit LCD displays. The setting range is 0.000A to the full scale of the CC mode specification. This parameter can be adjusted by turning the rotary knob. - ISTOP: Setting the stop current point. The LCD display shows “OCP”, “ISTOP” and 120.0A (actual value depends on 41T Series model) from top to bottom on the 5-digit LCD displays. The setting range is 0.000A to the full scale of the CC mode specification. This parameter can be adjusted by turning the rotary knob. - Vth: Setting the threshold voltage. The LCD display shows “OCP”, “Vth” and 0.50V (or initial setup value) from top to bottom on the 5-digit LCD displays. The setting range is 0.00V to the full scale of the Voltage specification. This parameter can be adjusted by turning the rotary knob. - START/STOP Test key. Press START/STOP key to start or stop the OCP when the OCP test function is enabled. The Load will go to the “ON” state automatically when the “START/STOP” key is pressed and start the OCP test. The load will return to the “OFF” state automatically when the “START/STOP” key is pressed to stop the OCP test. The load will remain in the “ON” state if the load was “ON” before OCP test execution. The OCP test function tests the UUT’s over current protection function. The OCP test will start sinking current from I-START and increase by ISTEP current until the UUT’s output voltage drops below the threshold voltage(V-th setting), and the OCP trip point is between the A_Hi and A_Lo limit settings. The lower 5- digits LCD display will shows "PASS", otherwise it will show "FAIL". Press any key to return to normal mode LCD display.

KEY#	Description
19	OPP key and LED Functions - OPP test function Enable/Disable Key. Press the “OPP” key to enable the OPP test function and the indicator LED will be lit. The LCD display show “OPP” on right 5 left LCD display, shows “PRESS” on middle 5-digit LCD display and shows “START” on the lower 5-digit LCD display. - OPP test function parameter setting key. There are four parameters for the OPP test function. These parameters are: PSTAR, PSTEP, PSTOP and Vth. Press the “OPP” key again to set the OPP test parameter PSTAR (start power point). Press the “OPP” key again to proceed to the next parameter in order of PSTEP, PSTOP, Vth and Disable. Press any other key to exit and save the OPP setting. The OPP test parameter descriptions are as follows: - PSTAR: setting the start power, The LCD display shows “OPP”, “PSTAR” and 0.00W (or initial setup value) from top to bottom 5 digits LCD display, the setting range is 0.00W to the full scale of the CP mode specification. The setting is by rotating the dial. - STEP: setting the increment step power, The LCD display shows “OPP”, “PSTEP” and 0.00W (or initial setup value) from top to bottom 5 digits LCD display, the setting range is 0.00W to the full scale of the CP mode specification. The setting is by rotating the dial. - PSTOP: setting the stop power, The LCD display shows “OPP”, “PSTOP” and 1200.0W (or initial setup value) from top to bottom 5 digits LCD display, the setting range is 0.00W to the full scale of the CP mode specification. The setting is by rotating the dial. - Vth: Setting threshold voltage; The LCD display shows “OPP”, “Vth” and 0.50V (or initial setup value) from top to bottom 5 digits LCD display, the setting range is 0.00V to the full scale of the Voltage specification. The setting is by rotating the dial. - START/STOP Test key. Press START/STOP key to start or stop the OPP test when the OPP test function is enabled. The load will go to the “ON” state automatically when the “START/STOP” key is pressed and start the OPP test. The load will return to the “OFF” state automatically when the “START/STOP” key is pressed to stop the OPP test. The load will remain in the “ON” state if the load was “ON” before OPP test execution. The OPP test function tests the UUT’s over power protection function. The OPP test will start sinking current from PSTART and increase power by PSTEP until the UUT’s output voltage drops below the threshold voltage (V-th setting), and the OPP trip point is between the P_Hi and P_Lo limit settings. The lower 5- digits LCD display will shows "PASS", otherwise it will show "FAIL". Press any key to return to normal mode LCD display.

KEY#	Description
20	START/STOP key Operation - Press START/STOP key to start or stop the short test by SHORT, OCP & OPP test setting parameter when SHORT, OCP & OPP test function is enabled. - The load will go to "ON" automatically when pressing the "START/STOP" key to start the short test and the load will go to "OFF" automatically when pressing the "START/STOP" key to stop the short test. The load will stay to "ON" if it was "ON" before short test. - The SHORT, OCP & OPP test functions are used to test the circuit protection of a unit under test. These tests will sink the load's maximum current or power to apply the test condition. If the UUT's voltage drop is between the V_Hi and V_Lo limits programmed, the lower 5-digit LCD display will show "PASS", otherwise it will show "FAIL". Press any key to return to normal mode LCD display.
21	Rotary Shuttle Knob Right Knob: Adjust flash digit value clockwise to increase set value.  Right Knob: Adjust flash digit value counter-clockwise to increase set value.  Left Cursor key: Moves the flashing digit over to the left by one position.  Right Cursor key: Moves the flashing digit over to the right by one position. 

KEY#	Description
	Up Cursor key: Increments flashing digit setting value by one count.
	Down Cursor key: Decrements flashing digit setting value by one count.
	NOTE: • In CR MODE, the Right and Up Cursor keys decrease setting value. • In CR MODE, the Left and Down Cursors keys increase setting value.
22	Load Input Banana Jack connectors. See section 5.6, "Load Connections" for details.
23	External voltage sense connectors. (V_{SENSE}). See section 7.5, "Voltage Sense Input Terminals" for details.
24	I-Monitor output BNC connector. See section 7.6, "Current Output Monitor (I-Monitor)" for details.
25	Module installation mounting screw. See section 5.2, "Load Module Installation and Removal in Mainframe" for details.
26	FUSE Test Mode Menu
27	BMS (Battery Management System) Test Menu

Table 6-1: Front Panel Display and Keyboard Functions

6.5 Operating Flowchart for 41T Series Load Modules

The flow chart on the next page shows the typical load current level and status setting procedures of each load module within a 44M0X mainframe. Load channel numbers 1 to 4 represent modules from left to right in the mainframe respectively. If the mainframe used has fewer than 4 slot positions, skip the corresponding module number.

- The strings shown in the square blocks are programming commands. Please follow the flow chart sequence for optimal and effective load settings.
- The load mode (CC, CR, CV, CP) should be set first. For CR and CV modes, only Static mode is available. For CC and CP modes, both Static and Dynamic modes are available.
- Next, choose high or Low load level and set the load levels for Static mode, or set the six parameters for Dynamic mode.
- The Limit key sets the GO/NG check upper and lower limits for DVM (voltage), DAM (current), and DWM (power) respectively.
- The system configuration settings for V-sense control, Load ON voltage, and load OFF voltage is part of the Limit setting.
- Other keys (Load ON/OFF, Short ON/OFF) can be controlled independently.




Figure 6-3: Operation Flow Chart - 41T Series Load Module

6.6 Go/NoGo LIMIT Testing

The 41T Series load modules have built in Go/NoGo test capability as part of their measurement systems. This allows abnormal conditions to be detected automatically so an EUT can be passed or rejected quickly in a production test environment.

6.6.1 Limits

The Go/NoGo is based on comparing measurement data against user provided upper and lower limit settings for voltage, current and power in the LIMIT system.

This creates a GO band (shown in green in the illustrations below) and a NoGo area. If the measurements fall inside the green zone, the test continues with the next step in an auto sequence. If not, a NoGo condition is flagged.

Go/NoGo has different implications depending on the operating mode selected. This is illustrated in the diagrams below.

6.6.2 Go/NoGo Testing in CC Mode

In constant current mode, the voltage limits are used to determine the pass or fail area for the input voltage.




Figure 6-4: LIMIT Test in CC Mode

6.6.3 Go/NoGo Testing in CC Dynamic Mode

In dynamic constant current mode, the voltage limits are used to determine the pass or fail area for the input voltage.




Figure 6-5: LIMIT Test in Dynamic CC Mode

6.6.4 Go/NoGo Testing in CR Mode

In constant resistance mode, the voltage limits are used to determine the pass or fail area for the input voltage.




Figure 6-6: LIMIT Test in CR Mode

6.6.5 Go/NoGo Testing in CV Mode

In constant voltage mode, the current limits are used to determine the pass or fail area for the load current.




Figure 6-7: LIMIT Test in CV Mode

6.6.6 Go/NoGo Testing in CP Mode

In constant power mode, the current limits are used to determine the pass or fail area for the input voltage.





Figure 6-8: LIMIT Test in CP Mode

6.7 TURBO Mode

This mode allows the load to support up to four times the rated current and power of a 41T Series load for short periods of time.

Turbo mode is very valuable for enhanced protection testing of power products. Examples include power supplies, Battery Management Systems (BMS) and protection devices such as Fuses / Breakers or PTC Resettable fuses. In so doing, the 41T Series can test and verify the actual trip current levels and response times under the abnormal operating conditions.

The following example illustrates the ease of performing these kinds of test with the 41T Loads.



5. Turbo mode ON/OFF indicator, Turbo mode includes Short, OCP, OPP, BMS and Fuse test functions, the others new functions are MPPT with CC and CR mode, CV response time setting, Battery discharge Batt1 ~ Batt3 in Config key.
6. Fuse (Current Protection Components) Test function key.
7. BMS (Battery Management System) test mode key.
8. Add CC+CV and CP+CV for battery discharge test.

In addition to the Turbo mode, the 41T loads also support NTC resistor simulation, which is an option on the 44M0xT series mainframe. These load functions support of a wide range of battery discharge testing. Particularly useful for these applications are the new CC + CV and CP + CV operation modes, battery discharge capacity test and dynamic cycle discharge test.

See subsequent sections for more details.

6.8 Power Supply Overload Testing

This function applies to AC/DC, DC/DC Power Supplies, DC/AC inverters, Power Adapters and Device Chargers. These products are not only designed to supply a stable voltage or current, they also need to protect load against abnormal conditions in order to ensure safe operation under all conditions. They are to prevent overheating or high temperature due to excessive current, which could result in a fire and other hazards.



Short circuit, Over Current and Over Power are all abnormal conditions. These conditions typically represent 125% to 150% of the normal rating and in some cases even more. Therefore, to simulate these abnormal conditions, the maximum current value and the maximum power value of the electronic load to perform these tests must be up to two times the normal rating. One solution is do use a load that is twice as big as needed for normal testing but this will cost more. A better alternative is to use the 41T Series loads, which can provide up to four times rated power and current conditions with a 'normal' rated model. The table below illustrates the capabilities of each 41T model load in this application.

Model		41T0630	41T0660	41T2512	41T5012	41T0615
Short / OCP / OPP Function						
Max. Current	TURBO OFF	30 A	60 A	12 A	12 A	15 A
	TURBO ON	90 A	180 A	36 A	24 A	60 A
Measurement Accuracy		± 1.0% (Reading + Range)				
Short Time	TURBO OFF	100 msec ~ 10 Sec. or Continuous				
	TURBO ON	100 ~ 1000 msec				
OCP Time (Tstep)	TURBO OFF	100 ms				
	TURBO ON	20 ms				
OPP Time (Tstep)	TURBO OFF	100 ms				
	TURBO ON	20 ms				


Table 6-2: Short / OCP / OPP Capabilities

The power supply products under test must respond with the appropriate protection function but the abnormal situation duration is often quite short. To test for these conditions, the 41T Series electronic load can increase the electronic load current and power in the new Turbo mode some period of time (within 1 second) up to 2 to 4 times the rated value. For example, the 41T0660 60V / 60A / 300W load in Turbo mode can increase its load current to 180A or power to 900W electronic load for up to one second. When verifying power products using Turbo mode in a production test environment, the 41T Series electronic loads offer greater test verification capability compared to conventional DC loads.


Furthermore, the 41T Series built-in measurement circuits can also measure the actual trip current value and protection response time under short-circuit or overload test conditions.

Examples of using Turbo mode for these tests are shown on next few pages.


6.8.1 SHORT Test Mode in Normal and Turbo Mode



6.8.2 Over Current Protection Mode in Normal and Turbo Mode



6.8.3 Over Power Protection Mode in Normal and Turbo Mode



6.9 MPPT Mode

Photovoltaic (PV) devices, such as solar panels and concentrated photovoltaic (CPV) modules, require outdoor testing for design verification, durability, and safety validation. A low cost means of testing the output power of PV devices under real world conditions is to use a DC electronic load capable of supporting the voltage range and power level of the cell or panel.

6.9.1 PV Panel Maximum Power Point

One of the key functions of outdoor PV testing is maximum power-point tracking (MPPT). Under any given lighting and temperature condition, there is only one voltage and current combination and thus only one load setting where the power output of the panel is at its highest. As conditions change, the load setting has to change as well to stay on the maximum power point.

But because electronic loads are general-purpose instruments, it is up to the PV test engineer to implement an algorithm in test software that allows the load to adjust itself in order to keep the panel under test at its maximum power point.

Fortunately, there are many MPPT algorithms to choose from, with several published papers on their implementation and performance. However, these algorithms were all designed for solar inverters, not electronic loads. Inverters are not test systems, so a MPPT algorithm that performs well in an inverter may not necessarily perform well as part of a PV test system.

6.9.2 DC Load vs Inverter MPPT Algorithms

The main difference between implementing a given MPPT algorithm in an inverter and an electronic load is in the I/O latency. In inverters, the MPPT algorithm runs on an internal microprocessor that can measure, compute and make load adjustments in microseconds. To perform the same set of operations with custom software and an electronic load could easily take tens of milliseconds due to the unavoidable I/O latency between the computer and the load. This I/O latency is a main bottleneck affecting tracking speed. With that in mind, the MPPT algorithm used in the 41T Series loads is specifically designed for test applications.

When testing a PV panel, the electronic load operates in constant voltage (CV) mode. This allows the power to be controlled by increasing or decreasing the amount of current the load draws from the panel. The load will adjust its internal resistance to remain at a set voltage as the current moves along the I-V curve of the panel. If the open circuit voltage of the panel (V_{oc}) drops below the load setting voltage, the load will act like an open circuit and the voltage across it will be whatever the V_{oc} of the panel is.

6.9.3 Load MPPT Algorithm

The algorithm used in the 41T Series loads is a modified version of the Perturbation and Observation (P&O) algorithm. The load MPPT algorithm works by making small adjustments in voltage (perturbation) and monitoring the effect on the panel's power output using its current and power measurement system (observation). This information determines if the

panel is at the maximum power point or not and if not, in what direction to move the current to remain at the panel's MPP.

The mathematical relationships of voltage and power that load uses to track the MPP can be expressed as:

- At MPP : $P_n - P_{n-1} = 0$
- Right of MPP : $P_n - P_{n-1} > 0$ and $V_n - V_{n-1} < 0$, $P_n - P_{n-1} \leq 0$ and $V_n - V_{n-1} \geq 0$
- Left of MPP : $P_n - P_{n-1} \leq 0$ and $V_n - V_{n-1} < 0$, $P_n - P_{n-1} > 0$ and $V_n - V_{n-1} \geq 0$

Where P_{n-1} is the previous power output and P_n is the present power output.




Figure 6-9: MMP Tracking Perturbation and Observation Chart

$P_n - P_{n-1} > 0$	$V_n - V_{n-1} > 0$	Location from MPP	Tracking Load
False	False	Left	Decrease
False	True	Right	Increase
True	False	Right	Increase
True	True	Left	Decrease

Table 6-3: MMP Tracking Perturbation and Observation Table

6.9.4 Manual MPPT Mode Operation

Press the “CONFIG” key 5 times to select the MPPT function and the initial tracking interval time is 2000mS than press “Start/Stop” key to going to track the MPP(The operation mode will be goes to CV mode and Load ON automatically.)

1. Connecting EUT (PV panel) to load input terminals
2. Press “Config” 5 times to MPPT function
3. Adjust the interval time (default 2000msec) using the dial cursor keys. The interval determines at what interval to record voltage, current and power measurement data in the internal memory buffer of the load. Buffer size is 720 readings sets. MPP tracking will be stop when the buffer is full. The memory will be cleared when power to the load is turned off or a new MPPT test is started.
4. Press Start/Stop to start tracking MPP of UUT
5. The voltage, current and power (MPP) is displayed on the load.
6. Press Start/Stop to stop to tracking the MPP of UUT.


6.9.5 Remote MMPT Programming

1. Send MPPTIME interval time, i.e. MPPTIME 1000.
2. Send command MPPT ON to start tracking MPP of UUT
3. Send MPP? command to read back the voltage, current and power (MPP)
4. Send MPPT OFF to stop tracking the MPP of UUT

6.10 Protective Current Device Test Mode

Common current protection devices include Fuses, Breakers and newer PTC Resettable fuses etc. Their role is to disconnect a load when the actual current exceeds the rated current of the load to avoid overheating, even fire, and other dangerous conditions. Therefore, the current protection component is the last line of defense to ensure safety when the load current is abnormal. When an abnormality occurs, the protective device must be able to provide the protection capability for disconnecting the circuit. The protection of these components have their own function and different price points. For example, a fuse is a one-time use device while circuit breakers and PTCs are reusable.

The current rating of the current protection component usually has a product relationship with the protection response time. The greater the current through the current protection component, the faster the reaction time. That means it is related to the total energy into the protection component.



To test these protection devices, the 41T Series electronic loads are specifically designed for test verification of current protection components. A Fuse Test function that can be used with Turbo mode that provides 2 to 4 times the rated current and power for a short period of time. This allows testing and verification of these components with about 3 times the current and power specifications of the components.

Model		41T0630	41T0660	41T2512	41T5012	41T0615
FUSE Test Mode						
Max. Current	TURBO OFF	30 A	60 A	12 A	12 A	15 A
	TURBO ON	90 A	180 A	36 A	24 A	60 A
Measurement Accuracy		± 1.0% (Reading + Range)				
Trip & Non-Trip Time	TURBO OFF	1 ~ 5999 msec, 6 ~ 16383 msec				
	TURBO ON	1 ~ 1000 msec				
Measurement Accuracy		± 0.04msec (< 200 msec), ± 20 msec (> 200 msec)				
Repeat Cycles		0 ~ 255				


Table 6-4: FUSE Test Mode Capabilities

Fuse Test functions are divided into two types, Trip (fuse) and Non-Trip (no fuse).


Fuse Test setting parameters include the test current (Pulse CC), the test time (PULSE TIME), the number of test repetitions PULSE REPEAT Cycles and the Ith or current threshold value.



41T Turbo mode OFF
Fuse Mode Test Result Screen




Setting: Turbo OFF, Fuse ON
CC Pulse 60A, 100ms, Repeat 3 Cycles




Setting: Turbo OFF, Fuse ON, CC Pulse 60A,
100ms, Repeat 3 Cycles - Waveform



41T Turbe Mode ON
Fuse Mode Test Result Screen



Setting: Turbo ON, Fuse ON
CC Pulse 180A, 100ms, Repeat 3 Cycles



Setting: Turbo ON, Fuse ON, CC Pulse 180A,
100ms, Repeat 3 Cycles - Waveform

The fuse Trip test determines that when the current is too large the device can provide the protection of an open circuit. This means the current protection components need to have a fuse action. To test this, the test current needs to be greater than the fuse current specification. After the fuse blows or Circuit Breaker trips, the load determines if the current is lower than the programmed I_{th} current threshold value. The load LCD will display the Repeat Cycle and the fusing time in ms.


For the Non-Trip test, the current protection component is required to achieve non-blown action, so the test current needs to be lower than the fuse current specification. To verify that at normal current levels the device does not trip, the load checks that during the test time (Pulse Time) the device does not trip after repeating the number of repeat cycles. The load LCD will display the number of Repeat Cycles applied.

6.11 BMS Test Mode

Lithium batteries are widely used in a variety of electronic products and electric vehicles and other devices. In order to protect the lithium battery from catching fire, exploding or any other dangerous condition, the lithium battery must be designed with a Battery Management System (BMS) protection circuit.

The BMS ensures the charging voltage does not exceed the maximum safe value of the lithium battery (Over Voltage Protection or OVP) during charge cycles. It also monitors discharge to ensure battery does short-circuit or exceed its rated current (Over Current Protection or OCP). Finally, internal battery and cell temperatures are monitored for over or under temperature protection (OTP/UTP).

The 41T Series electronic loads include standard BMS test functions. Furthermore, the new Turbo mode allows the short circuit protection current and overcurrent protection to be 2 to 4 times larger depending on model.



The BMS test function for lithium batteries includes short circuit and over current protection modes, which provide a quick, easy and accurate test solution. For BMS short-circuit protection, there is about four times more current available for OCP current testing. This function responds instantaneously (μ secs) to ensure adequate protection. Using the load, short circuit protection up to 180A can be tested.


The electronic load can also display additional BMS short circuit protection information such as BMS internal MOSFET switch off time and actual peak current value and response time.

For a typical BMS over current protection function, the difference between normal working current and short circuit current protection (OCP) is about 125% of rated current. The OCP must respond within a few hundred msecs.


To test BMS over-current protection, the load starts to sink current (I_{start}), then checks whether the BMS over-current protection is active. If the BMS over-current protection is not active, the load starts to increase the load current (I_{Step}) and checks whether the BMS OCP is responds. This process continues until the BMS OCP activates. Thus, the BMS OCP test can determine both OCP function current trip level and response time.

6.12 Battery Test Modes

The 41T Series load supports five battery discharge tests, TYPE1 ~ TYPE5. You can select the appropriate battery test mode and test results can be directly displayed on the LCD display showing the battery AH capacity, the discharge voltage value, the cumulative discharge time data etc.



There are also CC pulse cycle life test and CC Ramp Cycle life test types (Type 4 and Type5 modes are supported using remote control only). These can be used to simulate the battery in actual use by using a variety of load current changes and cycle variations. The user can verify and simulate the performance and life during actual use of batteries.



6.13 NTC Simulation (Option)

Based on the safety issues with lithium batteries and the effect of ambient temperature, lithium batteries and chargers must require a temperature protection mechanism to prevent causing danger under ambient low and high temperature conditions.



The 41T Series electronic loads and 44M0xT mainframe support an NTC resistor simulator option. The 41T Series can set NTC resistor values from 100Ω to $500K\Omega$, equivalent to $10K\Omega$ NTC resistance for a temperature range from -46°C to $+179^{\circ}\text{C}$. Changing the NTC resistance verifies if the lithium battery and charger temperature protection system operates correctly by either halting the charge or discharge cycle or by reducing the charge and discharge current. When the temperature returns to normal working temperature levels, the load checks if the protection action recovers and returns to the operational state, i.e. restores the normal charge and discharge.

6.14 Initial Power-on Settings

When powering up the 41T Series electronic loads, the initial load settings after power ON are as shown in the tables below respectively by model number. These are the factory default settings.

6.14.1 Model 41T0630 Initial Settings

Item			Initial value		Item			Initial value	
CC L+Preset			0.000 A		LIMIT	V_Hi		60.000 V	
CC H+Preset			0.000 A			V_Lo		0.000 V	
CR H+Preset			12000 Ω			I_Hi		30.00 A	
CR L+Preset			12000 Ω			I_Lo		0.0000 A	
CV H+Preset			60.000 V			W_Hi		150.00 W	
CV L+Preset			60.000 V			W_Lo		0.000 W	
CP L+Preset			0.000 W			CONFIG	SENSE		Auto
CP H+Preset			0.000 W		LD-ON		1.0 V		
DYN	T HI		0.050 ms		LD-OFF		0.500 V		
	T LO		0.050 ms		POLAR		+LOAD		
	RISE		125.0 mA/μs		MPPT		2000 msec		
	FALL		125.0 mA/μs		AVG		1		
	SUR_I		30.00 A		TURBO		OFF		
	NOR.I		0.000 A		BATT1		0.6 V		
	S.TIME		100		BATT2		10		
	S.STEP		1		EXTIN		OFF		
FUSE	CC		3A		CV_BW		1		
	TIME		10 ms		SHORT			Disabled	
	ITH		0.1 A		OPP			Disabled	
	REP		0		OCP			Disabled	
BMS	Disabled								

Table 6-5: Model 41T0630 Power-on Settings

6.14.2 Model 41T0660 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	60.000 V
CC H+Preset		0.000 A		V_Lo	0.000 V
CR H+Preset		60000 Ω		I_Hi	60.00 A
CR L+Preset		60000 Ω		I_Lo	0.0000 A
CV H+Preset		60.000 V		W_Hi	300.00 W
CV L+Preset		60.000 V		W_Lo	0.00 W
CP L+Preset		0.000 W		SENSE	Auto
CP H+Preset		0.000 W		LD-ON	1.0 V
DYN	T HI	0.050 ms	CONFIG	LD-OFF	0.500 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	250.0 mA/ μ s		MPPT	2000 msec
	FALL	250.0 mA/ μ s		AVG	1
	SUR_I	60.00 A		TURBO	OFF
	NOR.I	0.000 A		BATT1	0.6 V
	S.TIME	100		BATT2	10
	S.STEP	1		EXTIN	OFF
FUSE	CC	3A		CV_BW	1
	TIME	10 ms	SHORT		Disabled
	ITH	0.1 A	OPP		Disabled
	REP	0	OCP		Disabled
		Disabled			

Table 6-6: Model 41T0660 Power-on Settings

6.14.3 Model 41T2512 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	250.00 V
CC H+Preset		0.000 A		V_Lo	0.0000 V
CR H+Preset		1500 kΩ		I_Hi	12.000 A
CR L+Preset		1500 kΩ		I_Lo	0.000 A
CV H+Preset		250.000 V		W_Hi	300.00 W
CV L+Preset		250.000 V		W_Lo	0.0000 W
CP L+Preset		0.000 W	CONFIG	SENSE	Auto
CP H+Preset		0.000 W		LD-ON	2.0 V
DYN	T HI	0.050 ms		LD-OFF	0.500 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	50.0 mA/μs		MPPT	2000 msec
	FALL	50.0 mA/μs		AVG	1
	SUR_I	12.00 A		TURBO	OFF
	NOR.I	0.000 A		BATT1	0.6 V
	S.TIME	100		BATT2	10
	S.STEP	1		EXTIN	OFF
FUSE	CC	3A		CV_BW	1
	TIME	10 ms	SHORT		Disabled
	ITH	0.1 A	OPP		Disabled
	REP	0	OCP		Disabled
BMS	Disabled				

Table 6-7: Model 41T2512 Power-on Settings

6.14.4 Model 41T5012 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	500.00 V
CC H+Preset		0.000 A		V_Lo	0.0000 V
CR H+Preset		3000 kΩ		I_Hi	12.000 A
CR L+Preset		3000 kΩ		I_Lo	0.000 A
CV H+Preset		500.000 V		W_Hi	600.00 W
CV L+Preset		500.000 V		W_Lo	0.0000 W
CP L+Preset		0.000 W	CONFIG	SENSE	Auto
CP H+Preset		0.000 W		LD-ON	4.0 V
DYN	T HI	0.050 ms		LD-OFF	0.500 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	50.0 mA/μs		MPPT	2000 msec
	FALL	50.0 mA/μs		AVG	1
	SUR_I	12.00 A		TURBO	OFF
	NOR.I	0.000 A		BATT1	0.6 V
	S.TIME	100		BATT2	10
	S.STEP	1		EXTIN	OFF
FUSE	CC	3A		CV_BW	1
	TIME	10 ms	SHORT		Disabled
	ITH	0.1 A	OPP		Disabled
	REP	0	OCP		Disabled
BMS	Disabled				

Table 6-8: Model 41T5012 Power-on Settings

6.14.5 Model 41T0615 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	60.000 V
CC H+Preset		0.000 A		V_Lo	0.0000 V
CR H+Preset		240 kΩ		I_Hi	15.000 A
CR L+Preset		240 kΩ		I_Lo	0.00 A
CV H+Preset		60.000 V		W_Hi	75.000 W
CV L+Preset		60.000 V		W_Lo	0.0000 W
CP L+Preset		0.000 W	CONFIG	SENSE	Auto
CP H+Preset		0.000 W		LD-ON	1.0 V
DYN	T HI	0.050 ms		LD-OFF	0.500 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	62.5 mA/μs		MPPT	2000 msec
	FALL	62.5 mA/μs		AVG	1
	SUR_I	15.00 A		TURBO	OFF
	NOR.I	0.000 A		BATT1	0.6 V
	S.TIME	100		BATT2	10
	S.STEP	1		EXTIN	OFF
FUSE	CC	3A		CV_BW	1
	TIME	10 ms	SHORT		Disabled
	ITH	0.1 A	OPP		Disabled
	REP	0	OCP		Disabled
BMS	Disabled				

Table 6-9: Model 41T0615 Power-on Settings

6.14.6 Model 41T0880 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	80.400 V
CC H+Preset		0.000 A		V_Lo	0.000 V
CR H+Preset		60000 Ω		I_Hi	80.40 A
CR L+Preset		60000 Ω		I_Lo	0.0000 A
CV H+Preset		80.400 V		W_Hi	400.20 W
CV L+Preset		80.400 V		W_Lo	0.00 W
CP L+Preset		0.000 W	CONFIG	SENSE	Auto
CP H+Preset		0.000 W		LD-ON	1.0 V
DYN	T HI	0.050 ms		LD-OFF	0.670 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	337.5 mA/ μ s		MPPT	2000 msec
	FALL	337.5 mA/ μ s		AVG	1
	SUR_I	80.40 A		TURBO	OFF
	NOR.I	0.000 A		BATT1	0.804 V
	S.TIME	100		BATT2	10
	S.STEP	1		EXTIN	OFF
FUSE	CC	4.020 A		CV_BW	1
	TIME	10 ms	SHORT		Disabled
	ITH	0.134 A	OPP		Disabled
	REP	0	OCP		Disabled
		Disabled			

Table 6-10: Model 41T0880 Power-on Settings

6.14.7 Model 41T5020 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	500.00 V
CC H+Preset		0.000 A		V_Lo	0.0000 V
CR H+Preset		180E4 kΩ		I_Hi	20.400 A
CR L+Preset		180E4 kΩ		I_Lo	0.000 A
CV H+Preset		500.000 V		W_Hi	400.20 W
CV L+Preset		500.000 V		W_Lo	0.0000 W
CP L+Preset		0.000 W	CONFIG	SENSE	Auto
CP H+Preset		0.000 W		LD-ON	4.0 V
DYN	T HI	0.050 ms		LD-OFF	1.00 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	80.0 mA/μs		MPPT	2000 msec
	FALL	80.0 mA/μs		AVG	1
	SUR_I	20.400 A		TURBO	OFF
	NOR.I	0.000 A		BATT1	3.0 V
	S.TIME	100		BATT2	10
	S.STEP	1		EXTIN	OFF
FUSE	CC	1.020 A		CV_BW	1
	TIME	10 ms	SHORT		Disabled
	ITH	0.034 A	OPP		Disabled
	REP	0	OCP		Disabled
BMS					

Table 6-11: Model 41T5020 Power-on Settings

6.14.8 Model 41T0160 / 41T08160M Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	80.400 V
CC H+Preset		0.000 A		V_Lo	0.000 V
CR H+Preset		30000 Ω		I_Hi	160.20 A
CR L+Preset		30000 Ω		I_Lo	0.0000 A
CV H+Preset		80.400 V		W_Hi	800.40 W
CV L+Preset		80.400 V		W_Lo	0.00 W
CP L+Preset		0.000 W	CONFIG	SENSE	Auto
CP H+Preset		0.000 W		LD-ON	1.0 V
DYN	T HI	0.050 ms		LD-OFF	0.670 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	675.0 mA/ μ s		MPPT	2000 msec
	FALL	675.0 mA/ μ s		AVG	1
	SUR_I	80.40 A		TURBO	OFF
	NOR.I	0.000 A		BATT1	0.804 V
	S.TIME	100		BATT2	10
	S.STEP	1		EXTIN	OFF
FUSE	CC	8.010 A		CV_BW	1
	TIME	10 ms	SHORT		Disabled
	ITH	0.267 A	OPP		Disabled
	REP	0	OCP		Disabled
Disabled					

Table 6-12: Model 41T08160 / 41T08160M Power-on Settings

6.14.9 Model 41T5040 / 41T5040M Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	500.00 V
CC H+Preset		0.000 A		V_Lo	0.0000 V
CR H+Preset		900E3 kΩ		I_Hi	40.200 A
CR L+Preset		900E3 kΩ		I_Lo	0.000 A
CV H+Preset		500.000 V		W_Hi	800.30 W
CV L+Preset		500.000 V		W_Lo	0.0000 W
CP L+Preset		0.000 W	CONFIG	SENSE	Auto
CP H+Preset		0.000 W		LD-ON	4.0 V
DYN	T HI	0.050 ms		LD-OFF	1.00 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	160.0 mA/μs		MPPT	2000 msec
	FALL	160.0 mA/μs		AVG	1
	SUR_I	40.200 A		TURBO	OFF
	NOR.I	0.000 A		BATT1	3.0 V
	S.TIME	100		BATT2	10
	S.STEP	1		EXTIN	OFF
FUSE	CC	2.010 A		CV_BW	1
	TIME	10 ms	SHORT		Disabled
	ITH	0.067 A	OPP		Disabled
	REP	0	OCP		Disabled
BMS					

Table 6-13: Model 41T5040 / 41T5040M Power-on Settings

7 Load Connections, Applications and Protection Features

This section covers the following topics:

- Available connectors on the 41T Series load modules
- Connecting the load to various types of equipment
- Internal and External Voltage Sense
- Protection features

7.1 INPUT Terminals

The positive and negative terminals for load input connection are located on the lower front panel of the load module.

Note: Always refer to Section 2.3 “Safety Information” and Section 2.4 “Safety Notices” before making any load connections.

7.1.1 Banana Jack Connectors

This is the most common way for connecting the equipment to be tested with a 41T Series load. It is recommended that this connector be used when the load current is less than 20A as the maximum rated current of the plug connector is 20A. Please avoid exceeding maximum rated current to prevent damage caused by overheating. The maximum supported wire gauge for this connection method is AWG #14.

7.1.2 Y-hook / Spade Lug Terminals

Included in the 41T Series load module ship kit is a set of two (2) spade lug-type terminals. These can be used to crimp on to stripped wire ends of an EUT. Hook-type terminals provide good contacting characteristics. It is recommended that the hook-type terminal be used for any occasion where practical. The maximum supported wire gauge of the connection wires for this connection method is AWG #10.

7.1.3 Lead Wire Insertion

This is the simplest way to insert stripped ends of connecting wires into the holes on the metal portion of the input connector jacks. The maximum supported gauge of the connecting wire for this connection method is AWG #14.

7.1.4 Banana Jack Connector and Spade Lug Terminals

This combination method provides a higher current rating and lower impedance of the load connection. When input load currents are higher than 20A or the connecting lead wire is long, this method will be optimal.

7.1.5 Plug Connector and Lead Wire Insertion

This method can also be used when the input current is higher than 20A or the connecting lead wire is longer.

7.2 Wire Size

A major consideration in making input connection is the wire size. The minimum wire size is required to prevent overheating and to maintain good regulation. It is recommended that the wires are sized large enough to limit the voltage drop at the maximum current rating of the DC load to less than 0.5V per lead.

If needed, wire size can be increased by doubling the number of wires using two space lugs per side as shown in Figure 7-1.

7.2.1 Wire Size Guidelines

The following table provides a guide to the current carrying capability (ampacity) of Metric and AWG wire sizes. Metric sizes are expressed as a cross sectional area (CSA) in square millimeters. If in doubt regarding the rating of a cable or wire, consult your cable supplier.




Figure 7-1: Doubling wire size using spade lugs

Ampacity	AWG Size	CSA (mm ²)	Notes
5.0	22	-	Ampacity of aluminum wire is approx. 80% of copper rating
8.33	20	-	
10	-	0.75	When two or more wires are bundled together, ampacity
15.4	18	-	For each wire must be reduced to the following %:
13.5	-	1	
	16	-	2 conductors 94%
16	-	1.5	3 conductors 89%
31.2	14	-	4 conductors 83%
25	-	2.5	5 conductors 76%
40	12	-	
32	-	4	Maximum temperatures:
55	10	-	Ambient: 50°C / 122°F
40	-	6	Conductor: 105°C / 221°F
75	8	-	
63	-	10	
100	6	-	
135	4	-	

Table 7-1: Load Wire Size Table

Notes: AWG ratings are based on MIL-W-5088B, Metric size ratings are based on IEC Publications.

7.3 Connecting a UUT


WARNING

DO NOT EXCEED LOAD INPUT VOLTAGE RATING

This instrument does **NOT** have a means to disconnect its Load input from a connected power supply. If the voltage applied to the Load input exceeds its maximum rating – even if the load is turned completely off – damage to the load **WILL** occur. Damage caused by exceeded maximum load input voltage under any circumstance is **NOT** covered by the manufacturer’s product warranty. Remove any load input connections when the load is not in use, even when it is turned off.

When setting up for a new test and connecting any equipment to the DC load, proceed as follows:

1. Always make sure the DC load is turned OFF at the POWER switch when making any wire connections.
2. Check that the output of the equipment under test is **OFF**.
Note: Some power equipment’s output may still be energized even if the equipment has been turned off or its output is turned off. This is especially true for DC power supplies.

Note: When working with batteries, it is recommended to provide a suitable disconnect relay or switch so the load connection can be disconnected from the battery for handling purposes.

3. Connect one end of the load wires to the load input terminals.
4. Check the polarity of the connections and connect the other end of the load wires to the output terminal of the equipment under test.
5. When connecting multiple loads to the same EUT, makes sure the load wire lengths to each load are the same.

7.4 Polarity and Ground – Multiple Output Power Supplies

- It is recommended to connect the negative DC terminal to ground for positive output power supply EUTs.
- It is recommended to connect the positive DC terminal to ground for negative output power supply EUTs.
- When connecting multiple output DC power supplies, at all times, the potential of the positive DC load module input (Red binding post) **MUST** be at a higher potential than that of the negative DC load module input (Black binding post). Refer to the example show in Figure 7-2.




Table 7-2: Multiple Output DC Supply Polarity Connection

7.5 Voltage Sense Input Terminals

When the voltage sense mode is set to internal, the DC load module senses the DC at the input terminals of the DC load. Any voltage drop between the EUT and the load module across the load wires is not detected so the actual voltage at the EUT may be somewhat higher than is sensed by the load. For low current applications, the voltage drop may be negligible. Figure 7-2 shows the load connection with internal sense mode.




Figure 7-2: DC Load Connection with Internal Voltage Sense

To measure the UUT output DC voltage directly at the UUT terminals, external voltage sense mode must be used. The external voltage sense terminals are provided on the front panel of the load module for this purpose. Refer to Figure 7-3 for details on the V Sense terminal location and polarity. This mode is recommended for higher current applications or when voltage precision is important.




Figure 7-3: DC Load Connection with External Voltage Sense

7.6 Current Output Monitor (I-Monitor)

The I-Monitor terminal is designed to monitor the electronic load's input current or short current. An isolated amplifier output with 0V to 10V full scale output signal represents the zero to full scale current the electronic load is sinking.

Please refer to the I-Monitor voltage /current scaling values for each 41T Series load module in Section 4, "Technical Specifications".

7.6.1 Non-Isolated Output

The I-Monitor output can be used to display and capture the load current waveform on a digital storage oscilloscope to further evaluate the voltage and current waveform of a power supply under test.

Note: The I-Monitor is **non-isolated**. It is intended to support power supply development and testing and must be ground referenced.

To allow monitoring of both voltage and current simultaneously on a dual channel oscilloscope, care must be taken not to create ground loops. Most oscilloscope inputs are ground referenced and input channels are **not** isolated from each other.



CAUTION

The 41T Series Current Output Monitor or I-Monitor is NOT ISOLATED. Do NOT use the I-Monitor output with different channels to avoid common grounding problems. Improper connections may cause damage

7.6.2 Output Impedance

The I-Monitor output volt range is 0 to 10V. Output impedance is 1K Ω . The equivalent output circuit of the I-Monitor output is shown in the figure below.




Figure 7-4: Equivalent I-Monitor Output Circuit

7.6.3 Connecting I-Monitor Output to an Oscilloscope

When you connect the load's current monitor to an oscilloscope, please carefully check the polarities of the scope probes of the oscilloscope as shown in Figure 7-5.




Figure 7-5: Correct I-Monitor Connections to UUT and Oscilloscope

Reversing signal and ground on the voltage probe will result in a current to flow to ground as shown in Figure 7-6 and may damage the UUT, the oscilloscope and possibly the electronic load.




Figure 7-6: *Incorrect* I-Monitor Connections to UUT and Oscilloscope

7.7 Parallel Operation

It is possible to operate load modules in parallel if the power and/or current capability of a single load module is not sufficient.

7.7.1 Parallel Mode Connection

The positive and negative outputs of the power supply must be connected individually to each load module's input as shown in Figure 7-7 below. The setting is made at each individual load module. The total load current is the sum of the load currents being taken by each module.




Figure 7-7: Parallel Load Connection

7.7.2 Allowable Operating Modes

It is permitted to operate 4 series load modules with different voltage, current and power ratings to sink in parallel. For example the loads modules shown in Figure 7-7 could be a mixture of 41T0660, 41T0630, 42L0824, and 41D1020.

While in static mode, the load modules can be set to operate in CC, CR or CP mode.

7.7.3 Exceptions

1. Parallel operation in DYNAMIC mode is not allowed.
2. Parallel operation in CV mode is not possible.



7.8 Series Operation

Series operation of dc load modules to achieve higher voltage ranges than supported by an individual load module is **NOT** allowed under any circumstance.



7.9 Zero-Voltage Loading

As shown in Figure 7-8, the Electronic load can be connected in series with a DC voltage source (DC power supply in CV mode) with an output voltage greater than:

- 0.6Vdc (41T0630 & 41T0660),
- 1.0Vdc (41T2512),
- 6.0Vdc (41T5012)
- 0.3Vdc (41T0615)

This allows the device under test connected to the electronic load to be operated down to a zero volt condition. The external DC voltage source provides the minimum operating voltage required by the electronic load. This application is suitable for low voltage battery cell high discharge current testing.




Figure 7-8: Zero Volt Load Connection


7.10 Protection Features

The 41T Series electronic loads include the following protection features:

- Over Voltage
- Over Current
- Over Power
- Over Temperature
- Reverse Polarity Indication

7.10.1 Over Voltage Protection

The over voltage protection circuit is set at a predetermined voltage depending on the load model and **cannot** be changed. If the over voltage circuit has tripped, the load input turns OFF immediately to prevent damaging the load. When an over voltage trip condition has occurred, the digital current meter's LCD display will indicate "OVP"



7.10.2 Over Current Protection

The load always monitors the current it is sinking. When the current sink is greater than 105% of the rated maximum current, the load module will turn load to OFF state internally. When an over current condition has occurred, the digital current meter's LCD display will indicate "OCP".

7.10.3 Over Power Protection

The load always monitors the power dissipated by the load. When the power dissipation is greater than 105% of the rated power input, the load module will turn load to OFF state internally. When an over power condition has occurred, the digital current meter's LCD display will indicate "OPP".

7.10.4 Over Temperature Protection

As soon as the temperature of load's internal heat sinks reaches a level greater than 85° C (180° F), the over temperature protection is triggered. The digital current meter's LCD display will indicate "OTP". The load will turn to the OFF state internally.

Please check environmental conditions such as the ambient temperature and distance between the rear panel of the load chassis and any wall is greater than 15cm / 6 inches.

The load can reset the Over Voltage, Over Current, Overpower and Over Temperature protection if the condition that caused the fault is removed and the "LOAD" key is pressed to set "ON" state.

7.10.5 Reverse Polarity Protection Indication

The 41T Series electronic load conducts reverse current when the polarity of the DC source connection is incorrect. The maximum reverse current is a function of the load model. If the reverse current exceeds the maximum reverse current, it may damage the load.

When a reverse polarity current condition exists, the reverse current is displayed on the 5 digit current meter on the front panel, and the 5-digit DVM indicates a **negative** current reading. Whenever a reverse current is displayed on the current meter, turn OFF power to the DC source immediately and make the correct connections.

8 Auto Sequence Programming Examples

8.1 Overview

An auto-sequence allows the user to step through previously saved set-ups stored in the mainframe's memory. Up to nine auto-sequences can be saved. Each auto-sequence can consist of up to sixteen steps. There are two modes available for the auto-sequence function. These are **edit mode** - to set up an auto-sequence and **test mode** - to recall and start an auto-sequence execution.

8.2 Edit Mode

To set up a new auto-sequence using the Edit mode, proceed as follows:

1. Set-up all load parameters such as the operating mode, along with sink values and the LOAD ON/OFF status. Configuration and limit settings can also be set and the NG ON function may be selected as part of the setup.
2. Press the STORE key and one of the numbered STATE keys to store the set up in one of the memory locations. The BANK number can also be changed to provide additional memory locations.
3. Repeat the previous steps as needed to create additional load set-ups and saved them to separate memory locations using the STORE, BANK and STATE keys.
4. Once the required number of load setups has been saved enter the EDIT mode by pressing the EDIT key. The EDIT key will light up indicating the EDIT mode is active.
5. With the EDIT button lit, the auto-sequence identity (F1 to F9) can be selected using the numbered STATE keys.
6. Now select the first memory location by pressing the up/down arrow keys to select the BANK and STATE. This will become the first step of the AUTO-SEQUENCE.
7. Press ENTER to set the chosen BANK and STATE memory location.
8. Using the arrow keys set the test time (T1) and NG/LIMIT checking time (T2) for that step of the auto-sequence.
9. Press ENTER to save the time setting and move onto the next step of the auto-sequence.
10. Repeat steps 6 to 9 to as needed to enter up to 16 steps to form the auto-sequence.
11. Once the desired number of steps have been set, press the STORE button.
12. The LCD will show REP (repetitions).
13. Use the arrow keys to set the number of auto-sequence repetitions.
14. Press STORE to confirm the sequence edit.

This completes the programming sequence.

8.3 Test Mode

To execute a previously stored auto-test sequence, proceed as follows:

1. Press the TEST key on the mainframe to enter the TEST mode.
2. Use the numbered STATE keys (1 to 9) to select the previously saved auto-sequence.
3. Press ENTER to start the auto-sequence.
4. The LCD shows "PASS" or "FAIL" after testing.
If limits and the NG functions have been set and a test step fails, the mainframe LCD display will flash "NG". The user must then press ENTER to continue the auto-sequence execution or EXIT to abort the auto-sequence.
5. Press auto-sequence or EXIT at any time to abort an auto-test sequence.

8.4 AUTO TEST SEQUENCE Example

In this example, we will create a program based on following illustration of a varying current over time. A total of eight sequence steps will be needed to implement this sequence. The program executes steps 1 to 8 in sequence.




Figure 8-1: Auto-Test Sequence Example Illustration

The desired current levels and durations are shown in the table below.


Auto-sequence Step number	Memory BANK	Memory STATE	Current Value	Execution Time (T1+T2)
1	3	1	1.0 Adc	200 ms
2	3	2	5.0 Adc	200 ms
3	3	3	1.0 Adc	400 ms
4	3	4	5.0 Adc	400 ms
5	3	5	1.0 Adc	200 ms
6	3	6	10.0 Adc	1000 ms
7	3	7	1.0 Adc	1000 ms
8	3	8	0.0 Adc	1000 ms

Table 8-1: Auto-Test Sequence Example Values

To program this sample sequence, proceed as follows:

1. Set the operation mode: Press the mode key to CC mode.
2. Set the range: Press RANGE key to force range 2.
3. Set LOAD ON/OFF Status: Press load ON.
4. Set the current values steps 1-8 and store to memory BANK 3 STATES 1-8.
5. Press EDIT key.
6. Press the number 2 key to select F2 as the auto sequence location.
7. Press up/down key to memory bank 3 and state 1.
8. Press ENTER key to confirm the sequence memory.
9. Press up/down key to set the test time for that step (T1+ T2).
10. Press ENTER key to confirm the sequence step.
11. Repeat steps 7 to 10 to set auto-sequence steps 1-8.
12. After setting the final step, press the STORE key.
13. Press up/down key to 1 to repeat the auto-sequence one time.
14. Press STORE key to confirm the number of repetitions.
15. Press TEST key to enter TEST mode.
16. Press number 2 to select auto-sequence F2.
17. Press ENTER to confirm selection and start TEST.
18. The load will now step through the auto-sequence.

The current test waveform can be checked on an oscilloscope as shown below - assuming that the DC source can supply the programmed load currents.



9 Short Circuit, OPP and OCP Test Examples

9.1 Overview

This appendix provides examples on how to program the built-in test modes of the 5 Series loads. These tests allow commonly used functional testing of power supplies with minimal programming effort.

The parameters for the Short, Over Power Protection and Over Current Protection tests can all be programmed over the optional computer interfaces. The following examples may prove useful.

9.2 SHORT Test

To invoke short circuit testing of a unit under test, send the following sequence of commands to the load:

SHORT Test

This example sets a short test for 500ms until the STOP command is received.

REMOTE	Set Remote
TCONFIG	Set SHORT test function
SHORT	
STIME	Sets short time to 500ms time*
500	
START	Start SHORT testing
TESTING?	Ask Testing? 1:Testing, 0:Testing End
STOP	Stop SHORT testing
* if 500 is replaced with 0 the short test is continuous until STOP command	

9.3 OPP Test

To invoke over power protection circuit testing of a unit under test, send the following sequence of commands to the load:

OPP Test

In this example, threshold limits are set and the NG signal is enabled.

REMOTE	Set Remote	
TCONFIG	Set OCP test	
OPP		
OPP:START	Set start load watt 3W	
3		
OPP:STEP 1	Set step load watt 1W	
OPP:STOP 5	Set stop load watt 5W	
VTH 0.6	Set OPP VTH 0.6V	
WL 0	Set watt low limit 0W	
WH 5	Set watt high limit 5W	
NGENABLE	Set NG Enable ON	
ON		
START	Start OPP testing	
TESTING?	Ask Testing?	1:Testing, 0:Testing End
NG?	Ask PASS/FAIL?	0:PASS,1:FAIL
OPP?	Ask OPP watt value	
STOP	Stop OPP testing	

9.4 OCP Test

To invoke over current protection circuit testing of a unit under test, send the following sequence of commands to the load:

OCP Test

This test will start sinking current at 3A and increase to 5A in 1A steps.

REMOTE	Set Remote
TCONFIG	Set OCP test
OCP	
OCP:START 3	Set start load current 3A
OCP:STEP 1	Set step load current 1A
OCP:STOP 5	Set stop load current 5A
VTH 0.6	Set OCP VTH 0.6V
IL 0	Set current low limit 0A
IH 5	Set current high limit 5A
NGENABLE ON	Set NG Enable ON
START	Start OCP testing
TESTING?	Ask Testing? 1:Testing, 0:Testing End
NG?	Ask PASS/FAIL?,0:PASS,1:FAIL
OCP?	Ask OCP current value
STOP	Stop OCP testing.

10 Remote Control Programming

10.1 Overview

Program command syntax for all 4 Series load modules is contained in the 44M0xT mainframe operation manuals. Refer to any of the 44M01T, 44M02T or 44M04T operating manuals for the 4 Series mainframe:

Mainframe model 44M01T: P/N 160901-10-T

Mainframe model 44M02T: P/N 160902-10-T

Mainframe model 44M04T: P/N 160904-10-T

11 Calibration

11.1 Overview

All APS products ship with factory calibration. No additional calibration is required when first received.

11.2 Calibration Interval

The recommended calibration interval for these loads is one year (12 months). Routine annual calibration can be performed by most calibration labs that have low frequency measurement and power calibration capabilities. Alternatively, the load can be returned to the manufacturer to obtain a factory calibration.

11.3 Calibration Coefficients

The 44M04 mainframe requires no calibration but the 41T, 42L, 41D and 42D load modules do. All calibration is performed through software. No manual internal adjustments have to be made as part of routine calibration.

Calibration coefficients for the following parameters and functions are stored in non-volatile memory:

Parameters	Coefficients Stored
Load Current	All modes, DC, Offset and Gain, High Range & Low Range
Resistance	All modes, DC, Offset and Gain, High Range & Low Range
Voltage Measurement	DC, Offset and Gain
Current Measurement	DC, Offset and Gain
Power Measurement	DC, Offset and Gain

11.4 Calibration Procedures

Certified calibration labs may request a copy of the calibration manual for the relevant load model by contacting the nearest Adaptive Power Systems company location. Refer to section 1, "Contact Information".

12 CE MARK Declaration of Conformity

Directive: 2004/108/EC

Product Name 41T Series, 41L Series, 42L Series, 41D Series, 42D Series DC Electronic Loads

Serial Number _____

The manufacturer hereby declares that the products are in conformity with the following standards or other normative documents:

SAFETY:

Standard applied IEC 61010-1:2001

EMC:

Standard applied EN 61326-1:2006

Reference Basic Standards:

EMISSIONS:

CISPR11: 2003+A1: 2004+A2: 2006
EN 61000-3-2: 2006
EN 61000-3-3: 2008

IMMUNITY:

IEC 61000-4-2: 2008
IEC 61000-4-3: 2008
IEC 61000-4-4: 2004 +Corr.1: 2006 +Corr.2: 2007
IEC 61000-4-5: 2005
IEC 61000-4-6: 2003+A1: 2004+A2: 2006
IEC 61000-4-8: 2001
IEC 61000-4-11: 2004

Supplemental Information:

When and Where Issued: March 28, 2014
Irvine, California, USA

Authorized Signatory

Loc Tran
Quality Assurance Inspector
Adaptive Power Systems

Responsible Person

Joe Abranko
Adaptive Power Systems
17711 Fitch
Irvine, California, 92649, USA



Mark of Compliance

13 RoHS & REACH Material Content Declaration

Adaptive Power Systems declares under its own responsibility that the products listed under **Product List** meet the European Union's Restriction on Hazardous Substances Directive RoHS 2.0 (2011/65/EU, 2015/863/EU and REACH 1907/2006/EC requirements. The hazardous substances and threshold values are shown in the following table. All the product(s) are fully compliant with the EU RoHS Directive.

Please visit the website for the latest information about the SVHC substances published by ECHA

<https://echa.europa.eu/candidate-list-table>

Substance Name	Threshold Value	Directive Requirements
Lead (Pb)	< 0.1% (1000 ppm)	2011/65/EU
Cadmium (Cd)	< 0.01% (100 ppm)	
Mercury (Hg)	< 0.1% (1000 ppm)	
Hexavalent Chromium (Cr6+)	< 0.1% (1000 ppm)	
Polybrominated biphenyls (PBBs)	< 0.1% (1000 ppm)	
Polybrominated diphenyl ethers (PBDEs)	< 0.1% (1000 ppm)	
Bis (2-ethylhexyl) phthalate (DEHP)	< 0.1% (1000 ppm)	2015/863/EU
Butyl benzyl phthalate (BBP)	< 0.1% (1000 ppm)	
Dibutyl phthalate (DBP)	< 0.1% (1000 ppm)	
Diisobutyl phthalate (DIBP)	< 0.1% (1000 ppm)	

Manufacturer/Importer

Company Name: Adaptive Power Systems


Company Address: 17711 Mitchell North, Irvine, CA 92614, USA

Product List:

DC Loads. 41T08160, 41T08160M, 41T5040, 41T5040M

Person is responsible for marking this declaration:

Date: 2021/08/25


William Yang

Index

A

AC Input	28
Accessories	22

C

CC+CP mode	17, 55
CC+CV	16
Configuration	47, 107
Connections	42, 95, 102
Constant Current .. 14, 15, 17, 20, 44, 47, 48, 50, 51, 52, 58, 66, 70, 71, 72, 78, 86, 87, 88, 89, 90, 91, 92, 93, 94, 103, 110	
Constant Power 14, 16, 20, 44, 47, 48, 50, 51, 52, 58, 67, 70, 73, 86, 87, 88, 89, 90, 91, 92, 93, 94, 103	
Constant Resistance.... 14, 15, 47, 48, 50, 51, 52, 58, 68, 70, 72, 86, 87, 88, 89, 90, 91, 92, 93, 94, 103	
Constant Voltage .. 14, 15, 47, 48, 50, 51, 52, 58, 70, 73, 80, 86, 87, 88, 89, 90, 91, 92, 93, 94, 103, 104	
Contact	8, 41
Contents	3
Cooling	28
CP+CV	17

D

Display	49, 50, 69
Dynamic mode	51, 56, 70

F

Features	21, 105
Frequency	18
Front panel operation	48

G

Go/NoGo	47, 53, 71, 72, 73
---------------	--------------------

I

Installation	9, 23, 39, 40, 69
--------------------	-------------------

L

LED	51, 52, 53, 55, 56, 58, 65, 66, 67
Level	52

M

MPP	60, 79, 80
MPPT ... 49, 58, 60, 63, 78, 80, 86, 87, 88, 89, 90, 91, 92, 93, 94	

O

OCP test	49, 50, 66, 112, 113
OPP test	49, 50, 67, 112

P

Parallel operation	103
Programming	43, 46, 80, 107, 114
Protection	25, 47, 95, 105, 106, 111
PV Panel	78

S

Series operation	103
Short test	49, 50, 65
Size	96
Slew rate	18
Specifications	24, 45, 100

T

Terminals	95, 99
Turn on	41

W

Warranty	9
Waveform	18
Weight	28



ADAPTIVE Power Systems

Worldwide Supplier of Power Equipment

Copyright © 2018, Adaptive Power Systems, Inc. (APS) • All Rights Reserved • No reproduction without written authorization from APS.